

C4 & HYDRO:EVOLVED

PARAMETER LIST

VERSION 4.1



SMARTRISE

Document History

Date	Version	Summary of Changes
February 5, 2024	4.1	Updated Document name to "C4 & HYDRO:EVOLVED PARAMETER LIST" Updated Document Presentation. Added the <i>Custom Mode Parameters</i> section. Introduced additional parameters. Reviewed existing parameters.
October 25, 2021	4.0	Added additional parameters. Removed <i>Inspection Mode Parameters</i> section.
November 4, 2020	3.0	Changed how document was written from the type of adjustment to parameters that pertain to certain topics. Added additional parameters. Added additional tables. Added Min Value column to all tables.
December 30, 2019	2.0	Changed cover page. New document formatting. Added parameters to all sections. Moved conversion chart to the new Appendix section.
March 28, 2019	1.0	Initial Release

Table of Contents

1	Adjust Parameters	1
2	Attendant Service Parameters	2
3	Battery Back-Up/Emergency Power Parameters	3
4	Brake Parameters	6
5	Car Call and Hall Call Parameters	13
6	Custom Mode Parameters.....	18
7	Comm Port Parameters.....	19
8	COP Board Parameters.....	22
9	CT Board Parameters.....	23
10	DAD Parameters.....	24
11	Discrete Hall Lantern Parameters	25
12	Door Parameters	27
13	Drive/Starter Parameters.....	41
14	Earthquake Parameters	43
15	EMS Parameters.....	44
16	Expansion Board Parameters.....	46
17	Fire Parameters	62
18	Flood Parameters.....	72
19	Floor Parameters.....	73
20	Hall Board Parameters	81
21	Independent Service Parameters	83
22	Landing System Parameters	84
23	Load Weighing Parameters	86
24	Miscellaneous Parameters	89
25	MR Board Parameters	105
26	NTS Parameters	106
27	OOS Parameters	108
28	Parking Parameters	109

29	Riser Board Parameters	110
30	Sabbath Parameters	112
31	S-Curve Parameters.....	115
32	Security Parameters	123
33	Speed Parameters.....	135
34	Swing Mode Parameters	147
35	XREG Parameters.....	150
	Appendix – Conversion Chart	153

List of Tables

Table 1: Attendant Service Parameters	2
Table 2: Battery Back-Up/Emergency Power Parameters	3
Table 3: Brake Parameters	6
Table 4: Car Call and Hall Call Parameters.....	13
Table 5: Custom Mode Parameters	18
Table 6: Comm Port Parameters.....	19
Table 7: COP Board Parameters	22
Table 8: CT Board Parameters	23
Table 9: DAD Parameters.....	24
Table 10: Discrete Hall Lantern Parameters	25
Table 11: Door Parameters	27
Table 12: Drive/Starter Parameters	41
Table 13: Earthquake	43
Table 14: EMS Parameters.....	44
Table 15: Expansion Board Parameters.....	46
Table 16: Fire Parameters	62
Table 17: Flood Parameters.....	72
Table 18: Floor Parameters.....	73
Table 19: Hall Board Parameters	81
Table 20: Independent Service Parameters.....	83
Table 21: Landing System Parameters	84
Table 22: Load Weighing Parameters	86
Table 23: Miscellaneous Parameters	89
Table 24: MR Board Parameters	105
Table 25: NTS Parameters	106
Table 26: OOS Parameters	108
Table 27: Parking Parameters	109
Table 28: Riser Board Parameters	110
Table 29: Sabbath Parameters	112
Table 30: S-Curve Parameters.....	115
Table 31: Security Parameters.....	123
Table 32: Speed Parameters.....	135
Table 33: Swing Mode Parameters	147
Table 34: XREG Parameters.....	150
Table 35: Conversion Chart	153

Page intentionally left blank.

1 Adjust Parameters

The parameters can be adjusted for a maximum decimal value of 255 – 65535. For assistance in converting the adjusted parameter, use the conversion chart (Appendix – Conversion Chart) to look up the corresponding value for the hexadecimal number required for the job.

2 Attendant Service Parameters

The table below lists the Attendant Service parameters.

Table 1: Attendant Service Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0104	Attendant Direction With CCB	Pressing a car call button assigns direction when on Attendant Service. This can be used instead of dedicated UP and DOWN direction buttons on the COP panel.	0	1	0
01-0303	Attendant Service Use Only Swing Mask	If enabled, the car will only serve the hall calls matching the swing mask in the attendant mode	0	1	0
01-0338	Attendant Service Use Swing and Normal Mask	If enabled, the car will serve the normal and swing hall calls on the attendant mode (param overridden by 01-303)	0	1	0
01-0352	Attendant Byp. Security	Ignores car call security when on Attendant service	0	1	0

3 Battery Back-Up/Emergency Power Parameters

The table below lists the Battery Back-Up/Emergency Power parameters.

Table 2: Battery Back-Up/Emergency Power Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0127	DISA E-Power	When set to ON, the car will ignore emergency power commands.	0	1	0
01-0157	ENA RegenOnEP	When set ON, enables the regen when the car is running on emergency power. By default, when set to OFF, the DBR will used instead of the regen when running on emergency power.	0	1	config
01-0166	EPWR Pretransfer Stall	When set to ON, if the emergency power Pretransfer input is active, cars stop in a faulted state wherever they are. When set to OFF, cars move to the nearest landing and go out of service with the door open. This option is used when system is wired to use Pretransfer input to delay cars both at the transfer into and out of emergency power.	0	1	0
01-0270	Battery Power Fire1 DZ_Stop	(Hydro only) When set to ON, when car is on fire, battery power is low, and the car is above the fire recall floor, it will stop at intermediate DZs before going to the recall floor.	0	1	0
01-0295	Auto Rescue Close Doors	After Auto Rescue recall completes, close the doors after 15s.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0299	AutoRescue Close Doors FireOnly	Used with AutoRescue_Close_Doors_on_Fire (01-0295), limited door closure to Fire Phase1 and Phase2. Mandatory starting A17.1 2007, also for California (E-10-01). If disabled, close the doors for all modes, still meeting A17.1	0	1	0
01-0300	AutoRescue WaitCCtoMove CloseonFF2 Off	AutoRescue WaitCCtoMove CloseonFF2Off	0	1	0
01-0312	Allow Inspection Movement on EP	Allow car movement while a car is on Inspection during E-Power.	0	1	0
01-0347	Epower Car Active On Inspection	When enabled, the car on inspection is supposed online and counted as on normal mode from the budget of Epower.	0	1	0
08-0129	Epower Priority Car	Sets the first car selected when on emergency power and the Auto Select input is active. NOTE: In Canada this is the fire car. Set to the index of the intended car.	0	7	0
08-0144	AccelDelay Rescue (100ms)	Sets the start of run delay between energizing the motor and commanding nonzero speed. This timer is used when on automatic Battery Rescue operation. This time is set in 100 millisecond counts.	0	255	30
08-0145	Group Priority	Selects which group has priority during an Emergency Power event and organizes cars accordingly.	0	8	0

Number	String	Description	Min Value	Max Value	Default Value
08-0186	NumEPCars	Sets the number of cars allowed to run during Emergency Power operation	1	8	1
08-0230	Maximum EP Group Cars	Maximum number of cars that can run in all interconnected groups during Emergency Power operation.	0	255	config
08-0232	Idle Time Before Recall	Epower Privileged Car Idle Time Before Recall - Minutes	0	3	2
08-0264	Rec Trv Dir Timeout 50ms	Traction: if the drive exceeds this timeout without giving any output to c4 controller about the recommended travel direction on battery rescue mode of operation, the car will go to the nearest floor.	0	255	220

4 Brake Parameters

The table below lists the Brake parameters.

Table 3: Brake Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0035	EBrake On OVSP	Enables dropping of the emergency brake for general overspeed faults. Enables the Latching General Overspeed fault (F65).	0	1	0
01-0044	DISA Brake Faults	"(Traction Only) Disables brake faults. This option should be left OFF and is for test purposes only. (Hydro Only) This option will disable serial valve board and serial soft starter faults. This option should be left OFF and is for test purposes only. "	0	1	0
01-0052	TestUnintendedMovement	When set to ON with MR board DIP 8B also on, the car is ready for unintended movement testing. The secondary brake and B2 contactor automatically pick when this feature is activated and will remain picked until unintended movement is detected. While this mode is active, manually picking the B1 contactor commands the primary brake to pick.	0	1	0
01-0054	Primary BPS NC	Changes the main brake's BPS input from a normally open to a normally closed contact	0	1	1
01-0055	Secondary BPS NC	Changes the secondary brake's BPS input from a normally open to a normally closed contact	0	1	1
01-0059	ENA Secondary Brake	Enables use of a secondary brake instead of a rope gripper	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0101	BPS Stuck High Drops EBrake	When set to ON, BPS stuck high fault drops Ebrake	0	1	0
01-0111	DISA BPS StopSeq	Disables primary BPS check during the motion stop sequence. This parameter is set via SETUP BRAKE SETUP PRIMARY SETUP BPS - STOP SEQ.	0	1	1
01-0112	DISA BPS Stuck Active	Disables primary BPS stuck picked check. This parameter is set via SETUP BRAKE SETUP PRIMARY SETUP BPS - STUCK ACTIVE.	0	1	0
01-0113	DISA BPS Stuck Inactive	Disables primary BPS stuck dropped check. This parameter is set via SETUP BRAKE SETUP PRIMARY SETUP BPS - STUCK INACTIVE.	0	1	0
01-0117	DISA Brake Overheat	When set to ON, brake overheat faults are suppressed.	0	1	0
01-0158	EBrake on ETS/ETSL	When set to ON, ETS and ETSL faults cause the rope gripper to drop.	0	1	0
01-0162	DISA BPS2 Stuck Active	Disables secondary BPS stuck picked check. This parameter is set via SETUP BRAKE SETUP SECONDARY SETUP BPS - STUCK ACTIVE.	0	1	0
01-0163	DISA BPS2 Stuck Inactive	Disables secondary BPS stuck dropped check. This parameter is set via SETUP BRAKE SETUP SECONDARY SETUP BPS - STUCK INACTIVE.	0	1	0
01-0170	DISA Latching Brake FIt	When set to ON, primary and secondary brake's MOSFET fault is not latching. When set to OFF, the faults require resetting the MR board (F199 and F210).	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0334	Enable 2nd primary brake	When set to ON, it enables second primary brake board when the secondary brake is disabled	0	1	0
01-0335	Enable BPS Stuck Low Fault While Running	When set to ON, the car will go to the next available landing and asserts fault BPS Stuck Low. When set to Off, the car will be faulted only when reaching the destination floor	0	1	0
01-0336	BPS Stuck Low Drops EBrake	When set to ON, BPS stuck low fault drops Ebrake (01-335 is a must).	0	1	0
01-0180	B Cont. NC	When set to ON, both primary and secondary B contactor inputs (MBC and MB2C) are normally closed	0	1	1
01-0212	ENA Brake V2	When set ON, brake network (MR SRU BN+/-) communication will be 125K baud CAN bus. When set to OFF, communication will be 25K baud. Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	1	config
08-0099	Brake Pick Voltage	Sets the primary brake's DC pick voltage	30	255	config
08-0100	Brake Hold Voltage	Sets the primary brake's DC hold voltage	30	255	config
08-0101	Brake Ramp Time Auto	Sets the time it takes the primary brake to ramp up to pick voltage while in automatic operation. Units are in 10 ms counts.	0	255	20
08-0102	Brake Pick Delay	Sets the time the primary brake maintains the pick voltage. Units are in 10 ms counts.	0	255	150
08-0103	Brake Relevel Voltage	Sets the primary brake's DC releveling voltage	0	255	config

Number	String	Description	Min Value	Max Value	Default Value
08-0104	Secondary Brake Pick Voltage	Sets the secondary brake's DC pick voltage	0	255	config
08-0105	Secondary Brake Hold Voltage	Sets the secondary brake's DC hold voltage	0	255	config
08-0106	Secondary Brake Ramp Time	Sets the time it takes the secondary brake to ramp up to pick voltage. Units are in 10 ms counts.	0	255	20
08-0107	Secondary Brake Pick Delay	Sets the time the secondary brake maintains the pick voltage. Units are in 10 ms counts.	0	255	150
08-0108	Secondary Brake Relevel Voltage	Sets the secondary brake's DC releveling voltage	0	255	config
08-0109	Brake Ramp Time Inspection	Sets the time it takes the primary brake to ramp up to pick voltage while in inspection operation. Units are in 10 ms counts.	0	255	20
08-0126	Resend Brake Timer	Sets the minimum send rate of packets sent to brake boards. Units are in 5 ms counts.	30	150	50
08-0149	BPS Timeout (100ms)	Sets the timeout for primary BPS stuck active and stuck inactive faults (F189/F190). Minimum of 3 seconds.	0	255	0
08-0150	BPS2 Timeout (100ms)	Sets the timeout for secondary BPS stuck active and stuck inactive faults (F256/F257). Minimum of 3 seconds.	0	255	0
08-0244	Brake Delay Primary 2 Secondary Pick	Delay between Pick of Primary Brake to Pick of Secondary (Emergency) Brake Pick.	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0246	Ext EBrake Drop 1m	Alternative method for configuring how long after a run the emergency brake drops. This value is set in minutes. When set to 255, the EBrake will be kept picked constantly unless the car is faulted. When set to 0, this option is suppressed and parameters EBrakeDropDelay_Auto_1ms (16-0891) and EBrakeDropDelay_Insp_1ms (16-0892) are used instead. https://dev.azure.com/smartrise-us/C4%20Development/_workitems/edit/1923/	0	5	0
08-0247	BrakePickDelayRLVL 10ms	Sets the start of run delay between picking the B2 contactor and picking the primary brake when starting a releveling run. For rope gripper jobs, this is the delay between commanding zero speed and picking the brake. This timer is set in 10 millisecond counts.	0	255	10
08-0249	BrakeRampTimeRLVL 10ms	Sets the time it takes the primary brake to ramp up to pick voltage while performing a releveling run. This timer is set in 10 millisecond counts.	0	255	20
08-0250	Brake2RampTimeRLVL 10ms	Sets the time it takes the secondary brake to ramp up to pick voltage while performing a releveling run. This timer is set in 10 millisecond counts.	0	255	20

Number	String	Description	Min Value	Max Value	Default Value
16-0880	BrakePickDelay Insp (ms)	Sets the start of run delay between picking the B2 contactor and picking the primary brake while on inspection. For rope gripper jobs, this is the delay between commanding zero speed and picking the brake.	0	65535	100
16-0881	BrakePickDelay Auto (ms)	Sets the start of run delay between picking the B2 contactor and picking the primary brake while on automatic operation. For rope gripper jobs, this is the delay between commanding zero speed and picking the brake.	0	65535	100
16-0882	AccelDelay Auto (ms)	(Traction Only) Sets the start of run delay between energizing the motor and commanding nonzero speed. This timer is used when on all automatic operation modes except Battery Rescue. This timer is set in millisecond counts.	0	65535	400
16-0883	AccelDelay Insp (ms)	(Traction Only) Sets the start of run delay between energizing the motor and commanding nonzero speed. This timer is used when on inspection mode. This timer is set in millisecond counts.	0	65535	400
16-0885	BrakeDropDelay Auto (ms)	Sets the stop sequence delay between reaching zero speed and dropping the primary brake while on automatic operation	0	3000	0
16-0886	BrakeDropDelay Insp (ms)	Sets the stop sequence delay between reaching zero speed and dropping the primary brake while on inspection operation	0	3000	0

Number	String	Description	Min Value	Max Value	Default Value
16-0887	DriveDropDelay Auto (ms)	Sets the stop sequence delay between checking BPS and dropping drive control while on automatic operation.	0	65535	1200
16-0888	DriveDropDelay Insp (ms)	Sets the stop sequence delay between checking BPS and dropping drive control while on inspection operation	0	65535	900
16-0889	MotorDropDelay Auto (ms)	Sets the stop sequence delay between dropping drive control and dropping the M contactor while on automatic operation.	0	65535	500
16-0890	MotorDropDelay Insp (ms)	Sets the stop sequence delay between dropping drive control and dropping the M contactor while on inspection operation.	0	65535	500
16-0891	EBrakeDropDelay Auto (ms)	Sets the stop sequence delay between reaching zero speed and dropping the secondary brake while on automatic operation	1000	65535	1000
16-0892	EBrakeDropDelay Insp (ms)	Sets the stop sequence delay between reaching zero speed and dropping the secondary brake while on inspection operation	0	65535	0
16-0893	B2DropDelay Auto (ms)	Sets the stop sequence delay between dropping the secondary brake and dropping the B2 contactor while on automatic operation	0	65535	500
16-0894	B2DropDelay Insp (ms)	Sets the stop sequence delay between dropping the secondary brake and dropping the B2 contactor while on inspection operation	0	65535	500

5 Car Call and Hall Call Parameters

The table below lists the Car Call and Hall Call parameters.

Table 4: Car Call and Hall Call Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0056	Auto Runs Terminal To Terminal R	Enables automatic rear car call runs between terminal floors when on Enter Car Calls menu on the MR board display. This option should be left OFF and is for test purposes only.	0	1	0
01-0074	Auto Runs Terminal To Terminal F	Enables automatic front car call runs between terminal floors when on Enter Car Calls menu on the MR board display. This option should be left OFF and is for test purposes only.	0	1	0
01-0090	CustomMode IgnoredCar Call F	Configure custom mode to ignore front car calls during test	0	1	0
01-0091	CustomMode IgnoredCar Call R	Configure custom mode to ignore rear car calls during test	0	1	0
01-0092	CustomMode IgnoreHall Call	Configure custom mode to ignore hall car calls during test	0	1	0
01-0106	CC Acknowledge	When set to ON, whenever a car call is placed, the CC Acknowledge output will be triggered. This is used in Canada for blind people.	0	1	0
01-0114	Random Hall Runs	Enables automatic hall call runs to random destinations when on the Enter Hall Calls menu on the MR board. This option should be left OFF and is for test purposes only.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0160	Car To Lobby Express	When the Car to Lobby input is asserted, the car stops answering hall calls. This parameter determines how it handles car calls. If this parameter is ON, the controller continues responding to car calls until none are left. The car then returns to the lobby. If this parameter is OFF, the car cancels any existing car calls and returns to the lobby floor immediately.	0	1	0
01-0188	En. Clear Car Call	When set to ON, pressing the DC button and a latched car call button at the same time cancels the car call	0	1	0
01-0191	Suppress Reopen OnGSW	When set to ON, reopening to hall calls are suppressed when the doors have already opened at a level, both GSW signals are made, and there is demand	0	1	1
01-0194	ENA Never Drop Hall Calls	When set to ON, the car always maintains its HML (latchable hall call mask), even when the car is in a mode of operation that does not support hall calls.	0	1	0
01-0232	AN CtrReverse DirCC	When set to ON, car will clear out car calls entered in a direction opposite the car's current movement direction.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0245	Run Random Runs F	Enables automatic front car call runs to random destinations when on the Enter Car Calls menu on the MR board. If on the Enter Hall Calls menu, the car enters hall calls to random floors. This option should be left OFF and is for test purposes only.	0	1	0
01-0274	ENA CAN OVF RST	When set to OFF, the CAN1 bus buffer will not be cleared when it is filled. When set to ON, the CAN1 bus buffer will clear when filled.	0	1	0
01-0305	Non-selective HC mode	When set to ON, enables "non-selective", single-button hall calls. All hall calls should be wired as down calls.	0	1	0
01-0306	Non collective mode	When set to ON, enables "non-collective" hall calls. Once a hall call is latched, additional hall calls cannot be entered until car completes current demand.	0	1	0
01-0308	Latch single CCs on non - collective mode	When set to ON, only one CC is allowed to be latched on non-collective mode	0	1	0
01-0314	Allow HC & CC with Viscosity	(Hydro) Allow Hall Calls and Car Calls when oil warming motor run cycles are active to heat Hydraulic Oil.	0	1	0
01-0323	Ignore Calls When Car Not Empty on Main Floor	Ignore HC/CC on main recall floor when the car is not empty and in normal mode	0	1	0
01-0325	Enable Single CC on VIP	Enable single CC when VIP mode services car calls	0	1	0
01-0324	Ignore Calls When Car Not Empty on Alt Floor	Ignore HC/CC on alternate recall floor when the car is not empty and in normal mode	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
08-0050	CC Dir. Change (50ms)	Sets the car call direction change delay. This delays the direction change after answering a car call to allow time for hall call assignment. Units are in 50 ms counts.	0	255	10
08-0134	VIP_HC_Transition Delay_50ms	Sets the time between when a VIP car arrives at the VIP HC floor with its doors fully open, and when the car can begin taking CCs. This timer may need to be extended for jobsites where the VIP HC does not appear to clear. 50ms counts.	0	255	20
08-0166	Attendant Buzzer Duration	Specifies how long to sound the buzzer to alert the attendant that a hall call was pressed. Units are in 100 ms counts.	0	255	0
08-0189	Dir. Change Delay (1s)	Sets the time to delay car direction changes. Allows time for passengers to enter their car calls. Units are in 1 second counts.	0	30	3
08-0204	Max Car Calls Per 250lb	Sets the max number of car calls that can be latched for every 250 lbs of in car weight. If this limit is exceeded, all car calls are cleared as an anti-nuisance measure. If set to zero, this feature is disabled.	0	255	0
08-0223	Max Car Calls Light Load	Number of Car Calls latched. In Light Load, if this limit is exceeded, all car calls are cleared as an anti-nuisance measure. If set to zero, this feature is disabled.	0	255	0
08-0242	Vip Idle Time 1s	Sets the time while on VIP from when the car completes all car calls to servicing VIP Hall Calls.	0	255	10

Number	String	Description	Min Value	Max Value	Default Value
08-0269	Delay Between Calls Sec	A delay before servicing latched Car Calls and Hall Calls. This was requested by a job where the Doors do not automatically open, and user needs to activate the DOB button.	0	255	0
08-0271	Car Call Enable Delay Sec	Delay time between car call button and car call enable security key switch. In Seconds	0	255	0

6 Custom Mode Parameters

The table below lists the Custom Mode parameters.

Table 5: Custom Mode Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0340	Clear HC After Timeout On Custom Mode	When enabled, The HC of the current floor on custom mode with Auto door open disabled will clear the HC after (08-269) if the door remains closed	0	1	0
01-0345	DOB Momentarily On Custom Mode	The DCB is only constant pressure when 01-0096 is ON on custom mode while DOB is momentarily.	0	1	0

7 Comm Port Parameters

The table below lists the Comm Port parameters.

Table 6: Comm Port Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0047	Transmit Run Log	Enables transmission of run logs to the group network. UNUSED	0	1	0
01-0053	ENA Emergency Dispatch	When set to ON, triggering communication loss on any Riser board's hall network causes the car to move into Sabbath mode until communication is restored.	0	1	0
01-0135	ENA CPLD Offline	When set to ON, communication from system CPLDs are monitored for timeout. The timeout will be determined by parameter 08-173.	0	1	0
01-0156	ENA DuparCOP	Enables communication with Dupar COP.	0	1	config
01-0164	ENA Janus RS Fixture	"Enables Janus RS485 fixtures on CT/COP boards. Requires system power cycle after changing to clear the ""Need To Cycle Pwr"" fault (F83/F717/F718)."	0	1	config
01-0201	ENA CPLD V3	When set to ON, the uses hardware with CPLD v3_X software. When set to OFF, it uses hardware with CPLD v1_x software. System must be power cycled after changing this value.	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0204	ENA DL20 CT	"When set to ON, communication to DL-20 fixtures from the CT board is supported. Priority given to Janus emotive fixtures option (01-164). Requires system power cycle after changing to clear the ""Need To Cycle Pwr"" fault (F83/F717/F718)."	0	1	config
01-0205	Enable DL20 COP	"When set to ON, communication to DL-20 fixtures from the COP board is supported. Priority given to Janus emotive fixtures option (01-164). Requires system power cycle after changing to clear the ""Need To Cycle Pwr"" fault (F83/F717/F718)."	0	1	config
01-0210	ENA EX51 CT	When set to ON, communication to EX-51 fixtures from CT board is supported. Priority given to Janus emotive fixtures option (01-164).	0	1	config
01-0211	ENA EX51 COP	When set to ON, communication to EX-51 fixtures from the COP board is supported. Priority given to Janus emotive fixtures option (01-164).	0	1	config
01-0240	DISA CAM ON HA	When set to ON, disables the CAM output for the configured opening when performing a hoistway access top run or hoistway access bottom run.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0243	ENA SR Soft Starter	(Hydro Only) When set to ON at startup, the system expects to communicate with the SR serial soft starter. Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	1	config
01-0249	JackResync_IgnoreCalls	(Hydro Only) When set to ON, calls will not cancel a jack resync in progress.	0	1	0
01-0285	Group Redundancy Check	When set to ON, the controller will check if any communicating Riser Board has been offline for more than 10 seconds, in which it will then assert the Group Redundancy Output. Used for jobs that require Group Redundancy.	0	1	0
08-0171	Debug KEB Baud Rate	"This is a test parameter for adjusting the rate of communication with KEB drives. If changes, the corresponding adjustment must also be made on the drive. Allowed values: 0 = 115.2 kbps1= 9.6 kbps2 = 19.2 kbps3 = 38.4 kbps4 = 55.5 kbps"	0	255	0

8 COP Board Parameters

The table below lists the COP Board parameters.

Table 7: COP Board Parameters

Number	String	Description	Min Value	Max Value	Default Value
16-0024 through 16-0039	COP IN (1-16)	Set the COP board input terminal (1-16) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0416 through 16-0431	COP OUT (1-16)	Set the COP board output terminal (1-16) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

9 CT Board Parameters

The table below lists the CT Board parameters.

Table 8: CT Board Parameters

Number	String	Description	Min Value	Max Value	Default Value
16-0008 through 16-0023	CT IN (1-16)	Set the CT board input terminal (1-16) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0400 through 16-0415	CT OUT (1-16)	Set the CT board output terminal (1-16) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

10 DAD Parameters

The table below lists the DAD parameters.

Table 9: DAD Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0235	Disable Virtual Input	When set to ON, virtual inputs from the DAD unit are ignored.	0	1	0
01-0244	ENA DAD Flt Resend	When set to ON, enables minimum resend of fault and alarm packets sent to the DAD unit. Should be turned OFF for some job sites running older DAD software with a bug causing multiple instances of the same fault/alarm event to appear in the logs.	0	1	1

11 Discrete Hall Lantern Parameters

The table below lists the Discrete Hall Lantern parameters.

Table 10: Discrete Hall Lantern Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0175	Arv Lantern DR 1	When set to ON, set 1 of discrete arrival lantern outputs are for rear arrival. Set with 08-0197.	0	1	0
01-0176	Arv Lantern DR 2	When set to ON, set 2 of discrete arrival lantern outputs are for rear arrival. Set with 08-0198.	0	1	0
01-0177	Arv Lantern DR 3	When set to ON, set 3 of discrete arrival lantern outputs are for rear arrival. Set with 08-0199.	0	1	0
01-0178	Arv Lantern DR 4	When set to ON, set 4 of discrete arrival lantern outputs are for rear arrival. Set with 08-0200.	0	1	0
01-0179	Arv Lantern DR 5	When set to ON, set 5 of discrete arrival lantern outputs are for rear arrival. Set with 08-0201.	0	1	0
08-0168	Arrival Lantern Update Time	Sets the time before arriving at a floor to update arrival lantern outputs. If set to zero, arrival outputs update when doors begin to open. Units are in seconds.	0	10	3
08-0197	Arv Lantern FLR 1	Specifies the floor index for set 1 of discrete arrival lantern outputs. Set with 01-0175.	0	255	0
08-0198	Arv Lantern FLR 2	Specifies the floor index for set 2 of discrete arrival lantern outputs. Set with 01-0176.	0	255	0
08-0199	Arv Lantern FLR 3	Specifies the floor index for set 3 of discrete arrival lantern outputs. Set with 01-0177.	0	255	0
08-0200	Arv Lantern FLR 4	Specifies the floor index for set 4 of discrete arrival lantern outputs. Set with 01-0178.	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0201	Arv Lantern FLR 5	Specifies the floor index for set 5 of discrete arrival lantern outputs. Set with 01-0179.	0	255	0
08-0213	Hall Lantern Mask	Sets which hall lantern function groups are active. Each bit represents a different Hall board function. Power must be cycled to the MR SRU after setting this parameter to enable the feature.	0	255	config
08-0214	Rear Lantern Mask	Sets which hall lantern function groups are used for rear lanterns. Each bit represents a different Hall board function.	0	255	config

12 Door Parameters

The table below lists the Door parameters.

Table 11: Door Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0033	ENA Rear Doors	Enables rear doors if DIP 2B is turned on for the Machine Room (MR), Car Top (CT), and Car Operating Panel (COP) boards. Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	1	config
01-0041	ENA Releveling	Enables releveling when car is in door zone but outside the configured releveling zone (08-158)	0	1	1
01-0045	DZ Stuck High Test	Testing of DZ stuck high software solution. When ON, checks CTA for position rather than MRA.	0	1	1
01-0048	ENA Freight Doors	Enable freight doors. Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	1	0
01-0049	ENA FDR DCM	Enable freight doors fast close. UNUSED	0	1	0
01-0050	ENA FDR Auto Close	Enable freight doors auto close. UNUSED	0	1	0
01-0076	DR DC On Run	Activates door close output when in motion.	0	1	0
01-0079	OOS Rear Opening	Sets which door to open when recalled on out-of-service mode. Uses the rear door when set to ON.	0	1	0
01-0081	OOS SetDR Open	Keeps door open when at floor in out of service mode.	0	1	0
01-0084	Locks Jumped On DOL	When set to ON, detects jumper on open DOL instead of GSW.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0088	CustomMode AllowedOutsideDR Zone	Configure custom mode to allow outside door zone during test	0	1	0
01-0093	CustomMode AutoDR Open	Configure custom mode to automatically open the door during test.	0	1	0
01-0094	CustomMode DR Hold	Configure custom mode to hold the door during test.	0	1	0
01-0095	CustomMode IgnoreDCB	Configure custom mode to ignore door close buttons during test.	0	1	0
01-0096	CustomMode ForceDoorsOpenOrClosed	Configure custom mode to allow for forcibly open or close doors during test.	0	1	0
01-0108	DR DC On Closed State	Activates door close output while doors are in a closed state. This parameter is set via SETUP DOOR SETUP DC ON CLOSE.	0	1	0
01-0109	DR DO On Opened State	Activates door open output while doors are in a open state. This parameter is set via SETUP DOOR SETUP DO ON OPEN.	0	1	0
01-0115	CT ST SW Kills Doors	When set to ON, door outputs are suppressed when the Car Top Stop switch is active.	0	1	0
01-0118	DISA DoorsOnHA	When set to ON, door outputs on hoistway access inspection are suppressed.	0	1	0
01-0120	ENA AT400 DR	When set to ON, doors are configured for AT400 door operators. Both DC and NDG outputs are active for door close. DC is active, and NDG is inactive for door nudge.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0132	ParkingWithDR Open	"When set to ON, the door, based on 1-313 (On = rear / Off = front), is held open when the car is	0	1	0
01-0134	NoDemandDoorsOpen	When set to ON, car doors are held open when the car is idle.	0	1	0
01-0151	ENA Insp DO Out Of DZ	Enables opening doors while outside of a door zone during inspection	0	1	0
01-0159	ENA Open Doors Alarm	Enables a system alarm signalling when gate switch and locks are open during a run (A629)	0	1	0
01-0165	Learn Opening Time	When set to ON, if preflight is disabled (01-64), the car records the door opening time of its next run then stores it for use when preflight is enabled (08-187).	0	1	0
01-0189	ENA Dual PHE Test	Enables Dual PHE testing for freight doors	0	1	0
01-0193	ENA Passing Lobby DO	When set to ON, forces the car to stop and open its doors every time it passes the lobby floor. The lobby floor is the main fire recall floor.	0	1	0
01-0207	Door Retiring CAM	When set to ON, the CAM output controls hall interlocks. Otherwise, interlocks are controlled by the door operator. It is set to 0 when Mechanical retiring CAM is used instead of electrical CAM.	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0208	Fixed Hall CAM	When set to ON, the door has a fixed hall CAM. The car is allowed to start a run without hall locks (hall closed contacts still required). The car is allowed to move up to 2 feet without locks before faulting.	0	1	config
01-0209	Hall Closed Req for CAM	When set to ON, CAM does not energize if any hall door is open	0	1	config
01-0222	Freight Test PHE	When set ON, if either door is set to Freight (08-0012 or 08-0013 set to 1) door requires photoeye testing prior to closing doors. When set to OFF and for non-freight doors, this check is bypassed. This feature is required for Peelle door operators.	0	1	config
01-0237	DISA_DoorJumperCheck	When set to ON, door jumper check will be disabled. This should be turned OFF to enable Door Lock Monitoring.	0	1	0
01-0238	Nudge Without Onward Demand	When set to ON, the doors will begin to nudge (and the buzzer will fire if enabled) after a set time if the PHE is triggered and there is no command to move. Also, if the user would like the buzzer to fire whenever Nudge is commanded (even if there is no demand to move), turn this parameter ON.	0	1	config
01-0241	Disable Rear DOB	When set to ON, the rear DOB button is disabled.	0	1	0
01-0247	MLT_Fire1_DC	(Hydro Only) When set to ON, when the car hits MLT limit, doors will auto close after a phase 1 recall.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0255	DO OnArrivalOnly	For FRONT Doors - When set to ON, the Door Open output is activated on initial arrival at a landing. Once initial opening is complete, all open and close functions are done by DOB/DCB signals wired directly to the door operator. Set to ON for door operators from the company EMS, Courion, or Peelle (wired type). This parameter does not relate to the EMS (emergency medical service) mode of operation. Set this parameter if there is no PHE input defined for the door.	0	1	config
01-0256	InfiniteDwell Time	For FRONT Doors - When set to ON, configured dwell time is bypassed and doors will remain open. Used for swing/freight doors where door control is handled by the door operator. (i.e. courion door operator or Peelle wired door operator).	0	1	config
01-0264	DISA DCB ON NORMAL	When set to ON, pressing the DC button while the car is on normal operation will not cancel the door dwell time.	0	1	0
01-0265	DISA CLOSED CONTACTS DOB	When set to OFF, if a closed contact is open the car will see this as a DOB press. When set to ON this reopening behavior is suppressed. This is required for the Peelle door operator which expects the car's DC command when the closed contacts are open.	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0276	DO on Arrival Only R	For REAR Doors - When set to ON, the Door Open output is activated on initial arrival at a landing. Once initial opening is complete, all open and close functions are done by DOB/DCB signals wired directly to the door operator. Set to ON for door operators from the company EMS, Courion, or Peelle (wired type). This parameter does not relate to the EMS (emergency medical service) mode of operation	0	1	config
01-0277	InfiniteDwell Time R	For REAR Doors - When set to ON, configured dwell time is bypassed and doors will remain open. Used for swing/freight doors where door control is handled by the door operator. (i.e. courion door operator or Peelle wired door operator).	0	1	config
01-0279	JumperOnGS W_DOL	When set to ON, jumper on gateswitch faults (F98 and F107) are triggered when the gateswitch input indicates doors are closed, but the door open limit input indicates the doors are open. When set to OFF, these faults are triggered when the gateswitch input indicates the doors are open, but the door close limit input indicates the doors are open.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0288	Disable Freight Door Buzzer for DO Modes	When set on, disables the Freight Door Buzzer for Modes that Open the doors with zero dwell time. This does not disable the buzzer if the doors open with a Dwell time active or if the buzzer is needed during door closing.	0	1	0
01-0294	Automatic Freight Hall Door	Set when an automatic hall freight door is being used.	0	1	0
01-0313	Parking Opens Rear Door	When set to ON, the rear door opens when the car reaches the parking floor	0	1	0
01-316	Keep lights on DO	Allows the lamp to turn ON while the door is open	0	1	1
01-328	Active Shooter Close Doors	When set to ON, the lockdown feature is enabled on active shooter and therefore the doors stay closed and disabled on alternate floor.	0	1	0
01-0332	Access Dis. F Doors	When set to ON, it disables front doors to have access code.	0	1	0
01-0333	Access Dis. R Doors	When set to ON, it disables rear doors to have access code.	0	1	0
01-0349	CC Overrides the Door Hold Timer	When enabled, the Hold timer will cancel in case registering car call or activating door close button	0	1	0
01-0350	HC Buzzer Activation during Door Hold	When enabled, it triggers a buzzer if the door was on Hold and HC was entered on another floor	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
08-0000	DR Recall Time 1s	(Traction Only) Sets the time the doors remain open before closing after performing a recall on Fire phase 1. See A17.1 2007 and later, 2.27.3.1.6 (n)(3). (Hydro Only) Sets the time the doors remain open after performing a recall on an emergency modes like Fire and Battery Lowering. See A17.1 2019, 3.27.2.	0	15	config
08-0001	DR Dwell Time 1s	Sets the time car doors remain open when responding to car calls or open button requests. The units are in seconds.	0	255	3
08-0002	DR Stuck Time 1s	Sets the time limit for a door to complete an opening or closing request before faulting. The units are in seconds.	0	255	30
08-0003	DR Nudge Time 1s	Sets the time doors will spend trying to close before transitioning to nudging which ignores photoeye. If set to zero, nudging is disabled. The units are in seconds.	0	255	20
08-0004	DR Dwell Hall Time 1s	Sets the time car doors remain open when responding to hall calls. The units are in seconds.	0	255	6
08-0005	DR Dwell ADATime 1s	Sets the time car doors remain open when responding to ADA. The units are in seconds.	0	255	30
08-0006	DR Dwell Hold Time 1s	Sets the time car doors remain open when responding to door hold button requests. The units are in seconds.	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0007	DR Dwell Sabbath Time 1s	Sets the time car doors remain open while in Sabbath operation. The units are in seconds.	0	255	3
08-0008	DR Jumper Timeout 100ms	Sets the timer for jumper on Gate switch (F98/F107) and jumper on lock (F99/F108) faults. This value is added to a minimum timeout of 1.6 seconds. The units are in 100 millisecond counts.	0	255	0
08-0009	FDR Contacts Timeout 1s	Sets the timeout between CAM being energized and closed contacts being made. If value is zero, timeout is set to 500 ms. The units are in seconds.	0	255	20
08-0010	FDR GSW Locks Timeout 1s	Sets the timeout between GSW and locks. If value is zero, timeout is set to 500 ms. The units are in seconds.	0	255	30
08-0011	Lobby Dwell Time 1s	If set to nonzero, overrides the hall dwell time when at the lobby floor. The lobby floor is the main fire recall floor (08-111).	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0012	Door Type (F)	<p>Selects door type for Front doors</p> <ul style="list-style-type: none"> • 0=Automatic (used when CarDoor & HallDoor are auto) • 1= Freight (used with Freight doors, CarDoor can be manual/auto, HallDoor must be manual) • 2=Manual (used when both doors are manual) • 3=Swing (used when HallDoor is Swing & CarDoor auto) <p>Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).</p>	0	255	config
08-0013	Door Type (R)	<p>Selects door type for Rear doors</p> <ul style="list-style-type: none"> • 0=Automatic (used when CarDoor & HallDoor are auto) • 1= Freight (used with Freight doors, CarDoor can be manual/auto, HallDoor must be manual) • 2=Manual (used when both doors are manual) • 3=Swing (used when HallDoor is Swing & CarDoor auto) <p>Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).</p>	0	255	config
08-0014	Door Close Buzzer 100ms	<p>Sets the amount of time before doors begin to close that the door close buzzer will be turned ON. There is one buzzer output per door. This buzzer output remains on until doors are fully closed. This feature is used with the Peelle door operator.</p>	0	255	50

Number	String	Description	Min Value	Max Value	Default Value
08-0097	HA Top Opening	When nonzero, configures the top hoistway access to use the rear opening	0	255	0
08-0098	HA Bottom Opening	When nonzero, configures the bottom hoistway access to use the rear opening	0	255	0
08-0141	AN Max Opens Without PHE	Sets the max number of times that a car's doors can open without detecting a PHE transition. If this limit is exceeded, all car calls are cleared as an anti-nuisance measure. If set to zero, this feature is disabled.	0	255	0
08-0148	DR Hourly Fault Limit	Sets the number of door faults allowed within a 1-hour window before the car goes out of service. If the car goes out of service, it will remain out of service until the hour window elapses. If set to zero, there is no limit to the number of hourly door faults.	0	255	0
08-0185	Door Check Time 100ms	Sets the time the car doors must be seen as safe before the car is allowed to start a run in automatic operation. Time is set in 100 ms counts. If zero, defaults to 1 second.	0	255	3
08-0187	DR Opening Time (100ms)	Sets the estimated time it takes the doors to go from fully closed to fully open. This value is learned after performing a run with preflight disabled (01-64) and the learn opening time bit on (01-165). This can help improve dwell time delays when preflight is on. If set to zero, this option is disabled.	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0253	Drop Cam Outside DZ Idle Timer_1min	When set to non-zero, if the car is outside of the DZ, idle, and in auto operation, the car will assert the CAM until this timer expires.	0	255	0
08-0265	Door Zone Blade Size	Specifies the door zone blade size in inches.	6	24	6
08-0268	Inching Reduced Limit	The lower nibble defines be the adjustment for the Up direction, and the higher nibble for the Down direction. The values of these adjustments are incremented by 1 to compute the inching limits. Setting the parameter to 0 should result in a limit of (DZ/2 -1) in both directions to recover the old behavior.	0	255	0
16-0910	PreOpeningDistance	Sets the distance from a floor to start preopening doors. If zero, preopening is disabled. Units are in 0.019-inch counts.	0	131	26
32-0000	Front Opening Map 0	Front door opening map for floors 1 to 32. Edit via SETUP FLOORS OPENINGS (F). Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	4294967295	config
32-0001	Front Opening Map 1	Front door opening map for floors 33 to 64. Edit via SETUP FLOORS OPENINGS (F). Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	4294967295	config

Number	String	Description	Min Value	Max Value	Default Value
32-0002	Front Opening Map 2	Front door opening map for floors 65 to 96. Edit via SETUP FLOORS OPENINGS (F). Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	429496729 5	config
32-0004	Rear Opening Map 0	Rear door opening map for floors 1 to 32. Edit via SETUP FLOORS OPENINGS (R). Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	429496729 5	config
32-0005	Rear Opening Map 1	Rear door opening map for floors 33 to 64. Edit via SETUP FLOORS OPENINGS (R). Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	429496729 5	config
32-0006	Rear Opening Map 2	Rear door opening map for floors 65 to 96. Edit via SETUP FLOORS OPENINGS (R). Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	0	429496729 5	config
32-0032	WanderGuardMask0	Sets which floors the car should stop at with doors open when wander guard (aka Code Pink) mode is activated. Floors 1 to 32.	0	429496729 5	0
32-0033	WanderGuardMask1	Sets which floors the car should stop at with doors open when wander guard (aka Code Pink) mode is activated. Floors 33 to 64.	0	429496729 5	0

Number	String	Description	Min Value	Max Value	Default Value
32-0034	WanderGuardMask2	Sets which floors the car should stop at with doors open when wander guard (aka Code Pink) mode is activated. Floors 65 to 96.	0	4294967295	0

13 Drive/Starter Parameters

The table below lists the Drive/Starter parameters.

Table 12: Drive/Starter Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0058	DISA Auto Drive Reset	Disables the automatic reset of drive faults	0	1	0
01-0121	ENA DSD Full Field	When set to ON, full field is energized at the start of run instead of when the M contactor is picked. Setting this option reduces the time required to gain motor control.	0	1	0
01-0122	StopSeq DISA RampZero	Disables ramping down command speed from leveling speed to 1 fpm prior to dropping a run. This option must be OFF for KEB drives. (Hydro) Default On, stop cycle completes and preflight will be started before car speed reaches zero.	0	1	0
01-0123	StopSeq DISA Hold Zero	Disables stop sequence check for encoder speed to read below 1 fpm prior to dropping the brake. Turning this option OFF may increase floor level accuracy.	0	1	0
01-0128	ENA UIDriveEdit	Enables editing of drive parameters from the MR board or the group's GUI	0	1	0
01-0152	DSD Early Field ENA	When set to ON, the DSD drive field is energized as soon as the doors begin closing. This reduces start of run delays for consecutive runs. For this feature, 01-121 must also be set ON.	0	1	0
01-0154	TestTrcLoss	When set to ON, the drive's encoder speed is suppressed. This allows the traction loss fault to be artificially tripped.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0155	DISA InvertKEB SPD	By default, the system automatically sets the polarity of KEB's encoder speed signal (which by default is always positive). When set to ON, this feature is disabled.	0	1	0
01-0258	ENA HPV Serial Outputs	When set to ON, the HPV and M1000 drive outputs will be monitored serially. This option is for testing a new feature and will be removed in future versions.	0	1	0
08-0123	Drive Resend Timer	Sets the rate at which messages are sent to the drive. The units are in 5 ms counts.	0	255	2
08-0130	Drive Select	Sets the drive type the system is configured with: 0 = HPV, 1 = KEB, 2 = DSD, 3 = M1000, 4 = AC Quattro	0	255	config
08-0191	Debug NumInvalid Drive Packets	When nonzero, the car alters the checksum of sequential messages to the drive. Bad packets are sent on the rising edge of the MR board DIP 2A. This is used for debugging purposes only.	0	255	0

14 Earthquake Parameters

The table below lists the Earthquake parameters.

Table 13: Earthquake

Number	String	Description	Min Value	Max Value	Default Value
01-0042	ENA EQ	Enables seismic and counterweight derail modes of operation.	0	1	0
01-0246	EQ Buzzer	Turns the Auto Operation Buzzer on if on Seismic.	0	1	0
01-0287	EQ Buzz Until Safe	When set to ON, if EQ_Buzzer (01-0246) is also set to ON, the buzzer will fire when the car goes into Seismic or CW Derail. The buzzer will stop when the car has successfully recalled to a floor and fully opened the doors.	0	1	0
01-0298	EQ Buzz only on DOL	If this parameter is ON, it will override EQ_BuzzUntilSafe (01-287) and allow the buzzer to turn ON in Seismic or CW Derail only when doors are open. If set to 0, this parameter will not affect the system.	0	1	0

15 EMS Parameters

The table below lists the EMS parameters.

Table 14: EMS Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0051	Fire Overrides EMS Ph2	If turned ON, Fire Service will take priority over EMS2.	0	1	0
01-0097	EMS Allow Ph2 Without Ph1	Allows activation of Medical Phase 2 even if the car was never placed on Phase 1	0	1	0
01-0098	EMS Exit Ph2 At Any FLR	Allows exiting of EMS Phase 2 at any floor. Jobs with full hospital service should have this parameter turned ON. Jobs with EMT service should have this parameter OFF.	0	1	0
01-0100	Fire Overrides EMS Ph1	When set to ON, the activation of a smoke or Fire Phase 1 key causes a car that is currently on EMS Phase 1 to exit medical service and go on Fire Phase 1 recall. When turned OFF, the car remains on EMS Phase 1.	0	1	0
01-0292	Close Door on EMS2	When parameter is set, while car is on phase 2 close the door as soon as the car call is received. If the parameter is Off, after receiving the car call close the door with DCB to close the door.	0	1	0
01-0297	Diff Front/Rear doors in EMS2 CCs	When set to on, car calls in EMS2 differentiate between front and rear CCs. If set to off, both doors open after a CC.	0	1	0
01-0327	Enable first latched CC on EMS2	Enable first single CC, and disables other on EMS2	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
08-0163	EMS1 Exit Delay	When a car is called to a landing by an EMS Phase 1 key, this parameter specifies how long it will remain there before returning to normal operation if no one places it on EMS Phase 2. Units are in seconds.	30	255	60
08-0164	EMS2 Exit Delay	Specifies how long to wait after exiting EMS Phase 2 before returning to normal operation. A programmable delay allows time for the patient to be removed from the elevator if EMS Phase 2 were turned off prior to removing the patient. Units are in seconds.	0	255	1
08-0272	EMS1 Recall floor	A predefined floor when the EMS 1 service is activated via a key switch (enIN_MA_EMS1)	0	255	0

16 Expansion Board Parameters

The table below lists the Expansion Board parameters.

Table 15: Expansion Board Parameters

Number	String	Description	Min Value	Max Value	Default Value
16-0072 through 16-0079	EXP01 IN (1-8)	Set the Expansion1 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0080 through 16-0087	EXP02 IN (1-8)	Set the Expansion2 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0088 through 16-0095	EXP03 IN (1-8)	Set the Expansion3 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0096 through 16-0103	EXP04 IN (1-8)	Set the Expansion4 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0104 through 16-0111	EXP05 IN (1-8)	Set the Expansion5 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0112 through 16-0119	EXP06 IN (1-8)	Set the Expansion6 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0120 through 16-0127	EXP07 IN (1-8)	Set the Expansion7 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0128 through 16-0135	EXP08 IN (1-8)	Set the Expansion8 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0136 through 16-0143	EXP09 IN (1-8)	Set the Expansion9 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0144 through 16-0151	EXP10 IN (1-8)	Set the Expansion10 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0152 through 16 0159	EXP11 IN (1-8)	Set the Expansion11 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0160 through 16-0167	EXP12 IN (1-8)	Set the Expansion12 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0168 through 16-0175	EXP13 IN (1-8)	Set the Expansion13 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0176 through 16-0183	EXP14 IN (1-8)	Set the Expansion14 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0184 through 16-0191	EXP15 IN (1-8)	Set the Expansion15 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0192 through 16-0199	EXP16 IN (1-8)	Set the Expansion16 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0200 through 16-0207	EXP17 IN (1-8)	Set the Expansion17 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0208 through 16-0215	EXP18 IN (1-8)	Set the Expansion18 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0216 through 16-0223	EXP19 IN (1-8)	Set the Expansion19 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0224 through 16-0231	EXP20 IN (1-8)	Set the Expansion20 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0232 through 16-0239	EXP21 IN (1-8)	Set the Expansion21 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0240 through 16-0247	EXP22 IN (1-8)	Set the Expansion22 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0248 through 16-0255	EXP23 IN (1-8)	Set the Expansion23 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0256 through 16-0263	EXP24 IN (1-8)	Set the Expansion24 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0264 through 16-0271	EXP25 IN (1-8)	Set the Expansion25 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0272 through 16-0279	EXP26 IN (1-8)	Set the Expansion26 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0280 through 16-0287	EXP27 IN (1-8)	Set the Expansion27 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0288 through 16-0295	EXP28 IN (1-8)	Set the Expansion28 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0296 through 16-0303	EXP29 IN (1-8)	Set the Expansion29 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0304 through 16-0311	EXP30 IN (1-8)	Set the Expansion30 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0312 through 16-0319	EXP31 IN (1-8)	Set the Expansion31 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0320 through 16-0327	EXP32 IN (1-8)	Set the Expansion32 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0328 through 16-0335	EXP33 IN (1-8)	Set the Expansion33 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0336 through 16-0343	EXP34 IN (1-8)	Set the Expansion34 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0344 through 16-0351	EXP35 IN (1-8)	Set the Expansion35 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0352 through 16-0359	EXP36 IN (1-8)	Set the Expansion36 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0360 through 16-0367	EXP37 IN (1-8)	Set the Expansion37 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0368 through 16-0375	EXP38 IN (1-8)	Set the Expansion38 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0376 through 16-0383	EXP39 IN (1-8)	Set the Expansion39 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0384 through 16-0391	EXP40 IN (1-8)	Set the Expansion40 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0464 through 16-0471	EXP01 OUT (1-8)	Set the Expansion1 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0472 through 16-0479	EXP02 OUT (1-8)	Set the Expansion2 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0480 through 16-0487	EXP03 OUT (1-8)	Set the Expansion3 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0488 through 16-0495	EXP04 OUT (1-8)	Set the Expansion4 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0496 through 16-0503	EXP05 OUT (1-8)	Set the Expansion5 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0504 through 16-0511	EXP06 OUT (1-8)	Set the Expansion6 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0512 through 16-0519	EXP07 OUT (1-8)	Set the Expansion7 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0520 through 16-0527	EXP08 OUT (1-8)	Set the Expansion8 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0528 through 16-0535	EXP09 OUT (1-8)	Set the Expansion9 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0536 through 16-0543	EXP10 OUT (1-8)	Set the Expansion10 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0544 through 16--0551	EXP11 OUT (1-8)	Set the Expansion11 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0552 through 16-0559	EXP12 OUT (1-8)	Set the Expansion12 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0560 through 16-0567	EXP13 OUT (1-8)	Set the Expansion13 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0568 through 16-0575	EXP14 OUT (1-8)	Set the Expansion14 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0576 through 16-0583	EXP15 OUT (1-8)	Set the Expansion15 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0584 through 16-0591	EXP16 OUT (1-8)	Set the Expansion16 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0592 through 16-0599	EXP17 OUT (1-8)	Set the Expansion17 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0600 through 16-0607	EXP18 OUT (1-8)	Set the Expansion18 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0608 through 16-0615	EXP19 OUT (1-8)	Set the Expansion19 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0616 through 16-0623	EXP20 OUT (1-8)	Set the Expansion20 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0624 through 16-0631	EXP21 OUT (1-8)	Set the Expansion21 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0632 through 16-0639	EXP22 OUT (1-8)	Set the Expansion22 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0640 through 16-0647	EXP23 OUT (1-8)	Set the Expansion23 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0648 through 16-0655	EXP24 OUT (1-8)	Set the Expansion24 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0656 through 16-0663	EXP25 OUT (1-8)	Set the Expansion25 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0664 through 16-0671	EXP26 OUT (1-8)	Set the Expansion26 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0672 through 16-0679	EXP27 OUT (1-8)	Set the Expansion27 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0680 through 16-0687	EXP28 OUT (1-8)	Set the Expansion28 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0688 through 16-0695	EXP29 OUT (1-8)	Set the Expansion29 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0696 through 16-0703	EXP30 OUT (1-8)	Set the Expansion30 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0704 through 16-0711	EXP31 OUT (1-8)	Set the Expansion31 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0712 through 16-0719	EXP32 OUT (1-8)	Set the Expansion32 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0720 through 16-0727	EXP33 OUT (1-8)	Set the Expansion33 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0728 through 16-0735	EXP34 OUT (1-8)	Set the Expansion34 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0736 through 16-0743	EXP35 OUT (1-8)	Set the Expansion35 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0744 through 16-0751	EXP36 OUT (1-8)	Set the Expansion36 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0752 through 16-0759	EXP37 OUT (1-8)	Set the Expansion37 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0760 through 16-0767	EXP38 OUT (1-8)	Set the Expansion38 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0768 through 16-0775	EXP39 OUT (1-8)	Set the Expansion39 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0776 through 16-0783	EXP40 OUT (1-8)	Set the Expansion40 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
32-0029	Exp 24 Inputs Bitmap 0	Sets the index of 24 inputs board on the first 32 expansions	0	4294967295	config

17 Fire Parameters

The table below lists the Fire parameters.

Table 16: Fire Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0000	Fire Main Use Rear DR	Sets the door that opens after performing a main floor fire recall. Uses the rear door if set to ON.	0	1	config
01-0001	Fire Alt Use Rear DR	Sets the door that opens after performing an alternate floor fire recall. Uses the rear door if set to ON.	0	1	config
01-0002	Fire MAIN Use Alt FLR	Sets which recall floor to use when the smoke sensor located at the main recall floor is activated. Uses the alternate floor if set to ON.	0	1	config
01-0003	Fire Alt Use Alt FLR	Sets which recall floor to use when the smoke sensor located at the alternate recall floor is activated. Uses the alternate floor if set to ON.	0	1	config
01-0004	Fire MR Use Alt FLR	Sets which recall floor to use when the smoke sensor located in the machine room is activated. Uses the alternate floor if set to ON.	0	1	config
01-0005	Fire HW Use Alt FLR	Sets which recall floor to use when the smoke sensor located in the hoistway is activated. Uses the alternate floor if set to ON.	0	1	config
01-0006	Fire Main Flash Fire Hat	Flashes the fire hat output when the Main Smoke input is active	0	1	config
01-0007	Fire Alt Flash Fire Hat	Flashes the fire hat output when the Alternate Smoke input is active	0	1	config
01-0008	Fire MR Flash Fire Hat	Flashes the fire hat output when the Machine Room Smoke input is active	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0009	Fire HW Flash Fire Hat	Flashes the fire hat output when the Hoistway Smoke input is active	0	1	config
01-0010	Fire Main Shunt On Recall	Activates fire shunt output during Phase 1 recall if triggered by Main Smoke input	0	1	config
01-0011	Fire Alt Shunt On Recall	Activates fire shunt output during Phase 1 recall if triggered by Alternate Smoke input	0	1	config
01-0012	Fire MR Shunt On Recall	Activates fire shunt output during Phase 1 recall if triggered by Machine Room Smoke input	0	1	config
01-0013	Fire HW Shunt On Recall	Activates fire shunt output during Phase 1 recall if triggered by Hoistway Smoke input	0	1	config
01-0014	Fire Reset To Exit Phase1	The Fire Reset Key input must be active to exit Phase 1	0	1	config
01-0015	Fire DISA DR Restrictor Phase2	When set to ON, the door restrictor outputs are always turned OFF when the car is on Fire Phase 2.	0	1	config
01-0016	Fire Phase2 Swing Reopen DISA	When set to ON, the car ignores the position of the swing door on Fire Phase 2. NOTE: Set ON mostly just in NYC	0	1	config
01-0017	Fire Phase 2 Exit only at Recall Flr	The car must be at recall floor to exit Fire Phase 2	0	1	config
01-0018	Fire Ignore Locks Jumped On Phase2	Bypasses locks when on Fire Phase 2	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0019	Fire Stop Switch Kills DR Operator	Supress door outputs when Fire Stop Switch input is active. Also, with this parameter ON, during fire recall, IC stop switch should stop doors from closing if activated before recall begins. Once recall starts, IC stop should be suppressed until the car reaches the recall floor and opens its doors.	0	1	config
01-0020	Fire DOL To Exit Phase2	The car's Door Open Limit input must be active to exit Phase 2	0	1	config
01-0022	Fire Ok To Stop Outside DZ	N/A	0	1	config
01-0023	Fire Allow Reset With Active Smoke	Allows Fire Phase 1 reset with active smokes.	0	1	config
01-0024	Fire Hat Flash Ignore Order	Flashes fire hat for any active smoke. If OFF, only the first active smoke is checked.	0	1	config
01-0025	Fire Momentary DCB	When set to ON, when car is on fire phase 2 operation and the in car fire key switch is set to ON, pressing the DCB just momentarily will cause the door to close. When set to OFF, the DCB must be held until the door reaches the fully closed state, or the door will automatically reopen.	0	1	config
01-0026	Fire Flash Lobby Lamp	Enables flashing of the lobby fire lamp output	0	1	config
01-0027	Fire Remote And Main To Override Smoke	Both remote and Main Fire Key switch must be on to trigger main floor recall	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0028	Fire ENA PHE On Phase2	Enables photo eye during Fire Phase 2	0	1	config
01-0029	Fire DR Open On Hold	Hold doors open when on Fire Phase 2 hold	0	1	config
01-0031	Fire Pit Flash Fire Hat	Flashes the fire hat output when the Pit Smoke input is active	0	1	config
01-0032	Fire Pit Shunt On Recall	Activates fire shunt output during Phase 1 recall if triggered by Pit Smoke input	0	1	config
01-0036	Fire Pit Use Alt FLR	Sets which recall floor to use when the Pit Smoke input is active. Uses the alternate floor if set to ON.	0	1	config
01-0040	DISA BYP IC Stop	When set to ON, bypassing of IC stop switch is disabled. When set to OFF IC stop switch is bypassed during fire 2 recall, fire phase 1 recall, or ems phase 1 recall. For jobs that are compliant with A17.1-2016 code.	0	1	config
01-0046	Courion Fire1 Active	When turned ON, the output Fire I Active will stay asserted during the entirety of Fire Phase 1 (This is required for Courion Door Operators). If turned OFF, the output Fire I Active will assert until the car has finished Fire Phase 1 Recalling (This is required for PEELE Door Operators).	0	1	0
01-0119	EMS Fire 1 Active	When set to ON, the Fire 1 Active output will only fire when the car is on Fire Phase 1 and it is at the Recall floor. Required for EMS door operators for the Fire 1 Hold.	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0131	BYP FireSrv	When set to ON, bypasses fire service when DIP 6B on the MR board is also on. Bypassing fire service also clears any saved fire states.	0	1	0
01-0181	Enable Alt MR	When set to ON, the car looks for alternate MR and HA Smoke inputs. Used for groups split between two physical machine rooms.	0	1	config
01-0182	Fire MR 2 Flash Fire Hat	Flashes the fire hat output when the Machine Room 2 Smoke input is active	0	1	config
01-0183	Fire HW 2 Flash Fire Hat	Flashes the fire hat output when the Hoistway 2 Smoke input is active	0	1	config
01-0184	Fire MR 2 Use Alt FLR	Sets which recall floor to use when the Machine Room 2 Smoke input is active. Uses the alternate floor if set to ON.	0	1	config
01-0185	Fire HW 2 Use Alt FLR	Sets which recall floor to use when the Hoistway 2 Smoke input is active. Uses the alternate floor if set to ON.	0	1	config
01-0186	Fire MR 2 Shunt On Recall	Activates Fire Shunt output during Phase 1 recall if triggered by Machine Room 2 Smoke input	0	1	config
01-0187	Fire HW 2 Shunt On Recall	Activates Fire Shunt output during Phase 1 recall if triggered by Hoistway 2 Smoke input	0	1	config
01-0200	Fire Key FlashFireHat	Flashes the fire hat output when the fire recall key is active	0	1	config
01-0203	Fire Recall to Main After Phase 2	When set to ON, the car will fire-recall to the main floor after exiting Fire Phase 2. A17.1-2004 code.	0	1	0
01-0221	Fire2 Swing Reopen	When set ON, opening a swing hall closed contact will cause the doors to reopen.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0227	Fire DISA Latch Smokes	When set to OFF, the controller will remember the first smoke input it saw tripped until you exit fire service. The smoke will be remembered even across a power cycle. Most jobs except NYC will require this. This parameter is usually off for any controller that has a lobby fire key switch with a RESET position.	0	1	config
01-0228	Fire DISA Latch Lobby Key	When set to OFF, the controller latches the lobby key as the recall source until the key is turned from RESET to OFF. If set to ON, Fire Phase 1 is constantly reassessed when the recall source is the lobby key.	0	1	config
01-0229	Fire DISA Latch Main Recall	When set to OFF, if the car ever recalls to the main fire recalls floor, then it can't recall to the alternate floor until fire service has been reset. This is required by 2016 code.	0	1	config
01-0231	Fire Reset On Transition	When set to ON, resets Fire 1 on key switch position transition from RESET to OFF	0	1	1

Number	String	Description	Min Value	Max Value	Default Value
01-0267	EPWR DISA Fire1Lamp	When set to ON, in car fire lamp will behave as specified in the A17.1-2019 code. For A17.1-2019 the in car fire lamp should be suppressed when on fire phase 2, and the car is on emergency power but not selected to run. For A17.1-2010 the in car fire lamp should be suppressed when on fire and the car is not selected to run. A17.1-2.27.2.4.4 (b)	0	1	0
01-0268	Fire Exit Ph2 Without Ph1 Rcl	When set to ON, if the car is on fire phase 2, and fire phase 1 has been cleared via key switch, when the car is taken off fire phase 2, it will not attempt to return to the fire recall floor before exiting phase 1, instead it will return directly to normal operation. The car will also only exit fire phase 2 at the main recall floor. For addressing A17.1 2000, Florida testing procedures, https://dev.azure.com/smartrise-us/C4%20Development/_workitems/edit/1843 . When set to off, the car will return to the fire recall floor before returning to normal operation.	0	1	0
01-0275	ENA Phase1 EP Car Select	Enable support for A17.1 2008-2019 Section 2.27.2.4.5 Emergency Power Fire Phase 1 Car Selection.	0	1	config
01-0282	Fire Nudge with No Buzzer	When set to ON, while on Fire Service, the car will not assert the buzzer when nudge command is asserted.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0290	Fire 2 Active Always On During FP2	When set to ON, the output Fire II Active will assert whenever the car is on Fire Phase 2. Upon transitioning from Fire Phase 2 to Fire Phase 1, Fire II Active will drop, and Fire 1 Active will assert. This is used for non-peelee non-automatic doors that require Fire 1 Active and Fire 2 Active to control the door operation during Fire.	0	1	0
01-0307	Close door when PHE Bypassed on FF2	When set to ON, the door sends a close command instead of nudge if phe is bypassed on FF2	0	1	0
01-0309	Fire2 Bypass on MR and HA smoke	When set to ON, the Fire2 is bypassed if the origin of Fire1 is machine room or hoistway smoke	0	1	0
01-0310	Fire1 DOB HC Enabled Dwell 1 min	When set to ON, the Fire1 doors are cycled on recall, DOB and HC of recall floor after 1 min	0	1	0
01-0311	Only Exit FP1 on Main Landing	When Set ON, the car will only exit FP on the Main recall landing. A car that has been utilized for FP2 operation will remain in FP until returned to the main landing and switched Off FP2 after a FP1 reset	0	1	0
01-0317	Fire2 Cancel Button Reopen door	When Fire II cancel button is pressed while car on fire recall floor, the doors reopen	0	1	0
01-0319	Fire2 Close Door When No DOB	Closes the door on fire2 ON when DOB is not pressed	0	1	0
01-0320	Fire Switch 2 positions	When set to ON, the fire switches used on lobby and inside car are 2 positions	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0321	Fire No DCL to Exit phase2	When the car needs to exit fire2 and recall to lobby, the door should not be closed	0	1	0
01-0326	Fire1 reset extinguishes Lobby Lamp at Alt Floor	The lobby fire lamp turns off when fire1 is reset on alternate floor	0	1	0
01-0329	Turn Off At Recall Output on FP2	When enabled, turns off At Recall output when car is on FP2, and recall is finished	0	1	0
01-0341	Allow Shunt Trip on Inspection mode	When enabled, the shunt trip is enabled on inspection	0	1	0
01-0342	Allow Shunt Trip on Fire I Alternate Landing	When enabled, the shunt trip is enabled on Fire1 alternate floor	0	1	0
01-0343	Allow Shunt Trip on EMS	When enabled, the shunt trip is enabled on EMS	0	1	0
01-0344	Extinguish Fire Lamp On Special Operations	When enabled, the fire lamp is extinguished on low oil, motor overheat and battery rescue modes of operation	0	1	0
08-0111	Fire Main Recall FLR	Sets the main fire recall floor. This value is zero -based, so the bottom most floor is zero.	0	255	config
08-0112	Fire Alternate Recall FLR	Sets the alternate fire recall floor. This value is zero -based, so the bottom most floor is zero.	0	255	config
08-0224	ATTD Fire Recall Delay (1s)	Sets the delay before beginning fire recall when the car is parked at floor on attendant or independent service. See A17.1-2016 2.27.5.2(a).	10	30	20
08-0233	FireRecallKeyDebounce_100ms	Debounce counter for fire recall keyswitch inputs. Value is in 100msec counts.	0	127	10

Number	String	Description	Min Value	Max Value	Default Value
08-0251	LowBattery Fire2 RunLimit	When car is on Fire phase 2 travelling above the Recall fire floor and batterypower is triggered, the car Estops, then the value in this parameter will decide how many CCs the car will accept (CC will be always the floor below the floor it is at), then the car will return to the recall fire floor and fault out.	0	255	1

18 Flood Parameters

The table below lists the Flood parameters.

Table 17: Flood Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0102	Flood Override Fire	Allows flood operation to take priority over fire operation	0	1	0
01-0103	Flood Okay To Run	Allows car to continue to run above the configured flood sensor floor (08-165)	0	1	0
01-0278	Flood Flash Lamp	When turned ON, if the active mode of operation is Flood, the flood lamp will flash instead of being asserted high. (North Carolina Inspector stated that any sensor/switch in the shaft that has a relative lamp, will need it to flash).	0	1	0
08-0165	Number of Flood FLRs	Used in conjunction with the Flood Switch input. If a flood is detected, this parameter tells the controller which floors to avoid. If set to zero, the car can go to all floors. If the flood switch is active and this parameter is set to 1, the car is not allowed to go to the bottom floor. If set to 2 then the car can't go to bottom 2 floors, etc.	0	255	config

19 Floor Parameters

The table below lists the Floor parameters.

Table 18: Floor Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0062	Auto Runs FLR To FLR	Enables automatic one floor car call runs when on Enter Car Calls on the MR board. This option should be left OFF and is for test purposes only.	0	1	0
01-0074	Auto Runs Terminal To Terminal F	Enables automatic front car call runs between terminal floors when on Enter Car Calls menu on the MR board display. This option should be left OFF and is for test purposes only.	0	1	0
01-0077	Auto Runs FLR To FLR R	Enables automatic one floor rear car call runs when on Enter Car Calls on the MR board. This option should be left OFF and is for test purposes only.	0	1	0
01-0099	Auto Runs FLR To FLR F	Enables automatic one floor front car call runs when on Enter Car Calls on the MR board. This option should be left OFF and is for test purposes only.	0	1	0
01-0110	Run Random Runs R	Enables automatic rear car call runs to random destinations when on the Enter Car Calls menu on the MR board. If on the Enter Hall Calls menu, the car enters hall calls to random floors. This option should be left OFF and is for test purposes only.	0	1	0
01-0144	3 Digit PI	When set to ON, three -digit PIs are used.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0149	DISA CE FlrPlus1	When set to ON, the floor index sent to CE driver boards start at zero instead of one. Used for jobs where the annunciator was misconfigured.	0	1	0
01-0171	DISA PI OOS	When set to ON, OOS does not flash on the PI when the car is out of group.	0	1	0
01-0173	DISA DOB Secured Flr or Ignored opening	When set to ON, DOB is ignored for secured floors when the doors are fully closed or when the Car calls is ignored on a floor	0	1	0
01-0202	DISA Dest Loss Stop	When set to OFF, if a car is in flight to a floor and its destination lost and no alternate destination is detected, the car ramps down to the next reachable floor. When set to ON, this ramp down does not occur.	0	1	0
01-0225	ENA Ext Floor Limit	When set ON, the floor limit of the system is 96 floors instead of the usual 64.	0	1	config
01-0289	At Recall Lamp Lobby DOL	When set to ON, the At Recall output will assert when the car is at the lobby floor defined at 08-0122, and has the doors fully opened.	0	1	0
01-0355	At Recall Lamp Lobby Bypass DOL	When enabled it will operate in conjunction with Parameter 01-0289. When both parameters are activated, the system should trigger the output (lamp at recall) upon the car reaching a specific landing that can be set through parameter 08-0122 (Car to lobby FLR) disregarding DOL.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
08-0092	Number of FLRs	Sets the number of floors. Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	2	96	config
08-0094	HA Top Allowed Distance	Sets the distance below the top hoistway access floor that the car is allowed to move while on top hoistway access. The units are in feet.	0	255	9
08-0095	HA Top FLR	Sets the top hoistway access floor. This value is zero -based, so the bottom most floor is zero. This value's upper bound is the configured number of floors (08-93).	0	255	255
08-0096	HA BottomFLR	Sets the bottom hoistway access floor. This value is zero -based, so the bottom most floor is zero.	0	255	0
08-0110	HA Bottom Allowed Distance	Sets the distance above the bottom hoistway access floor that the car is allowed to move while on bottom hoistway access. The units are in feet.	0	255	9
08-0122	Car To Lobby FLR	Sets the floor the car moves to when the Car to Lobby input is activated. This value is zero -based.	0	255	0
08-0156	Relevel Offset Up 0.5mm	Reduces the releveling destination floor count by this value when approaching a floor from below	0	255	0
08-0157	Relevel Offset Down 0.5mm	Reduces the releveling destination floor count by this value when approaching a floor from above	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0158	Releveling Zone Size	Sets the size of the releveling zone (dead zone) in 0.02-inch position counts. When the car greater than this distance from the nearest learned floor position, and in door zone, it will attempt to relevel.	13	100	26
08-0169	Dest. Offset Up 0.5mm	Reduces the destination floor count by this value when approaching a floor from below	0	255	0
08-0170	Dest. Offset Down 0.5mm	Reduces the destination floor count by this value when approaching a floor from above	0	255	0
08-0172	Test Runs Dwell Time	Sets the dwell time used when testing the car using automatic call entry modes: Floor to floor (01-62) and random runs (01-114). Units are in seconds.	0	255	0
08-0174	Group Landing Offset	Sets the number of floors below the lowest serviced floor that are serviced by other group cars. This allows calls between different cars to be aligned so they refer to the same landing and is vital to proper dispatching.	0	31	config
08-0202	Check In Floor	Sets Check in Floor for when secure floors CC are latched.	0	255	0
08-0203	Move Idle Car Timer (10min)	Sets the amount of time the car is allowed to stay idle before it is forced to move to a random floor. This feature is used for cars using old DC machine with babbitt bearings that stick if the car is left idle for too long. If set to zero, this feature is disabled.	0	25	0
08-0231	Shuttle Mode Floor	Sets the floor the car moves to or from Main Fire recall floor, when the Shuttle mode input is activated. This value is zero - based.	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0239	Est F2F Time	(Hydro Only) Estimated average floor to floor time for this car. Used for destination dispatch call assignment calculations. This value must be manually entered by a user. Units are in seconds.	0	255	10
08-0261	Hard Stop Up floor	Selects the floor that the car should pass when going up.	0	255	0
08-0262	Hard Stop Down floor	Selects the floor that the car should pass when going down.	0	255	0
08-0266	Access Offset Floors	Specifies the number of offset floors that do not have access code. Useful to skip basements as an example.	0	96	0
08-0270	Recall Floor on Active Shooter Plus 1	"When greater than zero, the car recalls to the floor equal to (value -1) set in this parameter, else it goes to the fire alternate floor.			
16-0927	BufferDistance_05mm	Sets the distance between the bottom floor position and the buffer. This is used to determine ETSL point violations for reduced stroke buffer jobs.	0	65535	0
16-0958	ShortFloorOpening_0	Sets floors 1-16 as short floors. This setting is in bitmask form which each bit corresponds to a different floor index. Floors marked with 1 are not held to the same spacing requirements as standard floors. During a hoistway learn, their positions are auto set to a quarter inch from the previous floor and their position must be set manually via SETUP FLOORS STORE FLOOR LEVEL.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0959	ShortFloorOpening_1	Sets floors 17-32 as short floors. This setting is in bitmask form which each bit corresponds to a different floor index. Floors marked with 1 are not held to the same spacing requirements as standard floors. During a hoistway learn, their positions are auto set to a quarter inch from the previous floor and their position must be set manually via SETUP FLOORS STORE FLOOR LEVEL.	0	65535	0
16-0960	ShortFloorOpening_2	Sets floors 33-48 as short floors. This setting is in bitmask form which each bit corresponds to a different floor index. Floors marked with 1 are not held to the same spacing requirements as standard floors. During a hoistway learn, their positions are auto set to a quarter inch from the previous floor and their position must be set manually via SETUP FLOORS STORE FLOOR LEVEL.	0	65535	0
16-0961	ShortFloorOpening_3	Sets floors 49-64 as short floors. This setting is in bitmask form which each bit corresponds to a different floor index. Floors marked with 1 are not held to the same spacing requirements as standard floors. During a hoistway learn, their positions are auto set to a quarter inch from the previous floor and their position must be set manually via SETUP FLOORS STORE FLOOR LEVEL.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0962	ShortFloorOpening_4	Sets floors 65-80 as short floors. This setting is in bitmask form which each bit corresponds to a different floor index. Floors marked with 1 are not held to the same spacing requirements as standard floors. During a hoistway learn, their positions are auto set to a quarter inch from the previous floor and their position must be set manually via SETUP FLOORS STORE FLOOR LEVEL.	0	65535	0
16-0963	ShortFloorOpening_5	Sets floors 81-96 as short floors. This setting is in bitmask form which each bit corresponds to a different floor index. Floors marked with 1 are not held to the same spacing requirements as standard floors. During a hoistway learn, their positions are auto set to a quarter inch from the previous floor and their position must be set manually via SETUP FLOORS STORE FLOOR LEVEL.	0	65535	0
16-0983	Access Code Floor 1F	Sets the Access Code for Floor 1 Front	0	65535	0
16-0984	Access Code Floor 2F	Sets the Access Code for Floor 2 Front	0	65535	0
16-0985	Access Code Floor 3F	Sets the Access Code for Floor 3 Front	0	65535	0
16-0986	Access Code Floor 4F	Sets the Access Code for Floor 4 Front	0	65535	0
16-0987	Access Code Floor 5F	Sets the Access Code for Floor 5 Front	0	65535	0
16-0988	Access Code Floor 6F	Sets the Access Code for Floor 6 Front	0	65535	0
16-0989	Access Code Floor 7F	Sets the Access Code for Floor 7 Front	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0990	Access Code Floor 8F	Sets the Access Code for Floor 8 Front	0	65535	0
16-0991	Access Code Floor 1R	Sets the Access Code for Floor 1 Rear	0	65535	0
16-0992	Access Code Floor 2R	Sets the Access Code for Floor 2 Rear	0	65535	0
16-0993	Access Code Floor 3R	Sets the Access Code for Floor 3 Rear	0	65535	0
16-0994	Access Code Floor 4R	Sets the Access Code for Floor 4 Rear	0	65535	0
16-0995	Access Code Floor 5R	Sets the Access Code for Floor 5 Rear	0	65535	0
16-0996	Access Code Floor 6R	Sets the Access Code for Floor 6 Rear	0	65535	0
16-0997	Access Code Floor 7R	Sets the Access Code for Floor 7 Rear	0	65535	0
16-0998	Access Code Floor 8R	Sets the Access Code for Floor 8 Rear	0	65535	0
16-1046	Terminal Express floors	The MSByte is for top floor and the LSByte is for the bottom floor on terminal express mode of operation	0	65535	0
24-0000 through 24-0095	PI_0 through P1_95	N/A	0	16777215	config
24-0096 through 24-0191	LRN FLR 0 through LRN FLR 95	N/A	0	16777215	0

20 Hall Board Parameters

The table below lists the Hall Board parameters.

Table 19: Hall Board Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0195	ENA Ext. Hall Boards	When set to ON, they system is using 12-DIP Hall boards.	0	1	config
08-0146	Override Group Hall Mask	When the input "Override Group Hall Mask" is activated the car will use this parameter as a hall call mask for the car	0	255	0
08-0178	Linked Hall Mask 1	Sets which function groups of Hall boards that have their outputs tied together. For example, if set to 7 a hall button press triggers the lamp output on function 1, function 2 and function 3 Hall board for that floor. This value is a hall mask. See the C4 User Manual for more details on how these masks are set.	0	255	config
08-0179	Linked Hall Mask 2	Same as Linked Hall Mask 1. Used when multiple sets of linked hall buttons are needed.	0	255	config
08-0180	Linked Hall Mask 3	Same as Linked Hall Mask 1. Used when multiple sets of linked hall buttons are needed.	0	255	config
08-0181	Linked Hall Mask 4	Same as Linked Hall Mask 1. Used when multiple sets of linked hall buttons are needed.	0	255	config
08-0208	Hall Security Mask	Sets which Hall board address ranges require hall security. Set this parameter the same as the hall call mask (08-0209) is set. This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	255	config

Number	String	Description	Min Value	Max Value	Default Value
08-0209	Hall Call Mask	Sets which Hall board function groups the car. This function treats as regular hall calls.	0	255	config
08-0210	Hall Medical Mask	Sets which Hall board function groups are medical calls	0	255	config
08-0211	Hall Rear Door Mask	Sets which Hall board function groups are rear calls	0	255	config
08-0212	Swing Call Mask	Sets which Hall board function groups are swing calls	0	255	config
08-0258	Hall Medical Rear Door Mask	Sets which Hall board function groups are rear door medical calls. When set 08-0210 HallMedicalMask differentiates front, and this parameter defines rear. If zero, 08-0210 HallMedicalMask does both.	0	255	config

21 Independent Service Parameters

The table below lists the Independent Service parameters.

Table 20: Independent Service Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0236	Independent Srv. Ignore Front CCB	When set to ON, the Front CCB will be ignored while on Independent Service. (Feature Request).	0	1	0
01-0262	IND SRV CCB Closes Door	When set to ON, while on Independent Service, CCBs will close doors.	0	1	0
01-0318	Independent Service Overrides Reset Service Code	When set to on, Independent Service overrides the Reset Service Code and the elevator travels normally	0	1	0
08-0121	Group Car Index	Sets the car's group ID. This value is zero -based.	0	7	config
08-0125	Run Log Scaling	Sets the resolution of captured run logs. Units are in 50 ms counts.	0	255	4
08-0127	Motion Resolution	Sets the resolution of the commanded pattern. Units are in milliseconds.	3	20	10

22 Landing System Parameters

The table below lists the Landing System parameters.

Table 21: Landing System Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0038	ENA Landing Insp.	Enables Landing Inspection operation when the MR board DIP 3B is on.	0	1	0
01-0057	DISA CEDES Faults	Disables CEDES offline faults. This option should be left off and is for test purposes only.	0	1	0
01-0147	ENA CEDES2	Enables updated CEDES protocol v2.0.	0	1	0
01-0148	ENA 2nd Camera for ETSL TSRD	Enables a secondary CEDES unit (which connects to the COP) and ETSL/TSRD stop point checks. NOTE: Used for Canada jobs	0	1	0
01-0296	Enable ELGO	Enables ELGO Landing System. Overrides CEDES.	0	1	0
08-0243	CEDES Alarm Time 100ms	When a CEDES camera reports difficulty reading the tape an alarm signaling that maintenance cleaning needs to be performed will be asserted. A1457 to A1459. The CEDES read difficulty status is debounced by this timer. If this value is 0, the alarms are disabled. This value is in 100ms counts.	10	255	10
08-0260	APS Error Code Debounce	Debounce setting for detecting a consistent error on the APS system. (CEDES/ELGO)	0	255	8
16-0865	Acceptance Slide Distance	Distance in CEDES count that the car slides during ETSL slide test	0	65535	0
16-0866	Acceptance _EBrk_SlideDistance	Distance in CEDES count that the car slide during brake slide test.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0926	ETSL Camera Offset	The position difference between the primary CEDES camera and the ETSL camera. The ETSL camera is placed above the primary camera. This value is generated automatically when the car is put in learn mode. Units are in 0.019-inch counts.	0	65535	0
24-0192	COUNTER_ WEIGHT_MI D_POINT	The counterweight position is used to determine the recall floor during counter weight derailed operation. Units are in CEDES counts.	0	16777215	0

23 Load Weighing Parameters

The table below lists the Load Weighing parameters.

Table 22: Load Weighing Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0066	LWD ENA WiFi	When set to ON, the C4 system commands the Smartrise load weighing device to enable its Wi-Fi connection	0	1	0
01-0068	LWD Auto Recalibrate	When set to ON, the car regularly recalibrates its load weigher device	0	1	0
01-0070	LWD Trigger Recalibrate	When set to ON, the car performs a load weighing device empty load recalibration	0	1	0
01-0071	LWD Trigger Load Learn	When set to ON, the car performs load weighing device full load calibration	0	1	0
01-0078	Debug LWD	When set to ON, allows for viewing of load weighing device packet receive counts and raw load values.	0	1	0
01-0190	EnablePre torque Test	When set to ON, enables test feature which outputs a fixed pretorque value to the drive, specified by LWD_TorqueOffset (08-132)	0	1	0
01-0273	ENA LWD V2	When set to ON, serial LWD will use the improved calibration procedure for LWD v1.4.00 and later. When set to OFF, the serial SWD will use the calibration procedure for LWD v1.3.16 and prior.	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0281	RescueDirWithSerialLWD	When set to ON, a car on auto battery rescue will determine which direction to move using the pretorque value estimated by the C4 serial load weighing device. When set to OFF, the car will determine direction by discrete full load and light load signals (if 01-0105 is OFF) or the drive will determine the easiest direction (if 01-0105 is ON).	0	1	config
08-0132	LWD Torque Offset	Sets an offset to add to the Smartrise load weighing device torque percentage output. Value is a signed 8-bit integer.	0	255	0
08-0133	LWD Torque Scaling	Sets a scaling value to multiply by the torque output of the Smartrise load weighing device. The value is a signed 8-bit integer in percentage format.	0	255	0
08-0135	LoadWeigher Select	When set to zero, discrete load weigher signals are used.	0	255	0
08-0205	LWD Monthly Calibration Hour	Sets the time of day to automatically perform a load weighing device recalibration. Recalibration is performed on the first occurrence of this day on every month if automatic recalibration is enabled (01-0068).	0	255	23

Number	String	Description	Min Value	Max Value	Default Value
08-0206	LWD Monthly Calibration Day	Sets the day of the week to automatically perform a load weighing device recalibration. Recalibration is performed on the first occurrence of this day on every month if automatic recalibration is enabled (01-0068).	0	255	6

24 Miscellaneous Parameters

The table below lists the Miscellaneous parameters.

Table 23: Miscellaneous Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0030	VIP Priority Dispatching	Places car into VIP/Priority Dispatching. Allows for multiple cars in VIP mode to dispatch as a separate group.	0	1	config
01-0034	BYP Term Limits	Bypasses terminal limit faults. This option is automatically turned off when in automatic operation.	0	1	0
01-0037	ENA Pit Insp.	Enables Pit Inspection operation when the MR board DIP 4B is on.	0	1	0
01-0043	ENA Midflight Destination Change	Enables changing destination during a run. This option should be left ON and is for test purposes only.	0	1	1
01-0064	DISA Preflight	Disables the end of run preflight check	0	1	1
01-0072	ENA Construction Run Box	Enables use of Construction Run Box inputs instead of MR Up and MR Down buttons for construction operation motion. These inputs are labeled CUP, CDN, and MDC on the MR board.	0	1	0
01-0075	IC Insp.Req For CT	Requires in car inspection to enable car top inspection.	0	1	0
01-0080	DISA OOS	Disables out of service	0	1	1
01-0085	NC INPUT CustomMode	Configures custom mode of operation used for test	0	1	0
01-0105	Rescue Rec Trv Dir	Enables recommended travel direction check during automatic rescue operation	0	1	1
01-0107	DEBUG MonitorCarDirection	Display car's direction priority on the controller's home screen.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0116	DISA IdleTravelArrows	When set to ON, CE travel arrows reflect the motion direction of the car. When set to OFF, the arrows reflect the motion direction of the car and the arrival direction after a run.	0	1	0
01-0125	Debug FastGroupResend	Doubles the minimum send rate of group network packets necessary for dispatching. This should be set to ON for every car to fully enable this feature.	0	1	0
01-0129	ENA OpModeAlarm	Enables a system alarm signalling when the mode of operation changes (A146)	0	1	0
01-0130	ENA StopAtNextAlarm	Enables a system alarm signalling when a car is commanded to stop at the next available landing (A74). This can occur if the car's current destination has been cleared during a run.	0	1	0
01-0133	ENA LatchesCC	When set to ON, car call enable latches a car call.	0	1	0
01-0136	DebounceLatchedFault	When set to ON, the latching of safety faults is debounced for 6 seconds instead of the standard 2.5 seconds.	0	1	0
01-0142	Buzzer Only On Nudge	When set to ON, during nudging the NDG output is suppressed and only the buzzer sounds.	0	1	0
01-0145	DefaultFRAM	Set ON to default the FRAM chip. This option is self - resetting. This clears fault/alarm logs, latched faults, emergency bits, and run counter.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0150	ENA EStopAlarms	Enables a system alarm signalling when the Estop is commanded without a corresponding fault (A69 to A76)	0	1	0
01-0161	Double Chime On Down	When set to ON, the car chimes twice when the down arrow is activated. Set to OFF if the fixture automatically chimes twice.	0	1	0
01-0169	FRAM ENA Alarms	When set to ON, a FRAM corruption check on read fails an alarm displays.	0	1	1
01-0172	In Motion Opening Alarm	When set to ON, if car top output 614 (DO) is on during a run, an alarm is asserted (A631). This is used for debugging.	0	1	0
01-0198	CW Derail NO	When set to ON, CW derail inputs are normally open.	0	1	0
01-0199	ENA Board RTC	When set to ON, the onboard RTC is used instead of the D.A.D unit RTC.	0	1	0
01-0206	DISA DL20 Buzzer	When set to ON, DL20 fixture buzzer feature is suppressed.	0	1	config
01-0224	ENA Shield Alarms	When set ON, shield errors will be flagged as system alarms.	0	1	1
01-0226	ENA CE V2	When set ON, messages to the CE fixture driver board will include dedicated out of service and fire phase 2 messages.	0	1	0
01-0230	DISA_CPLD_ OVF_ALARM	When set to ON, disables the CPLD overflow alarm.	0	1	0
01-0233	ENA VIP T/O Alarm	When set to ON, if VIP has timed out an alarm will be asserted.	0	1	0
01-0239	EQ Old Job Support	When set to ON, the EQ lamp does not follow code 8.4.10.1(f) in order to support older jobs.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0248	FlashFireHat LowOil	(Hydro Only) When set to ON, on Low Oil operation car will flash fire hat.	0	1	0
01-0250	CAM Output On Move	When set to OFF, CAM will output when Car is in motion and not pre-opening. When set to ON, CAM will output when Car is outside Door Zone or in Motion.	0	1	0
01-0251	Motor Overheat Latch	When set to ON, the Motor Overheat fault will be a latching fault.	0	1	0
01-0252	Learn_Improved	When set to ON, learn operation will be performed on the car top instead of the machine room. This can improve the accuracy of learned floor positions.	0	1	0
01-0254	Secondary Valve Board	(Hydro Only) When set to ON at startup, the car will check for a secondary valve board which will support medium speed valves.	0	1	config
01-0259	Latch_CPLD _FLTS	When set to ON, CPLD preflight failure and redundancy failure faults will remain latched until power is cycled to the car.	0	1	1
01-0261	Secondary SS	(Hydro Only) When set to ON, the system will look for secondary soft starter signals.	0	1	config

Number	String	Description	Min Value	Max Value	Default Value
01-0266	Run With One SS	(Hydro Only) When set to ON, if two soft starters are supported, and only one of those soft starters is faulted, the car will still be allowed to run. In this situation, soft starter faults will instead be asserted as alarms. This option is only available if SecondarySoftStarter (01-0261) is ON.	0	1	0
01-0269	SS Flt Triggers Rst	(Hydro Only) When set to ON, if the soft starter fault input is activated, the controller will assert the soft starter reset output to power cycle the soft starter. This reset will be attempted multiple times before stopping.	0	1	config
01-0280	Enable TEI CC	When set to ON, the module TEI CC is initialized, and Marshal Mode is disabled. When set to OFF, Marshal Mode is enabled, and the module TEI CC is disabled. After changing this parameter, a power cycle is required.	0	1	0
01-0284	Bypass Term HA Inspection	When set to ON, while on HA Inspection, the car will be able to bypass term limits. Used in California for the run-by test.	0	1	0
01-0286	Arrival Lantern on DOL	When set to ON, the arrival lanterns will assert when the DOL is reached as opposed to on DO or before DO.	0	1	0
01-0304	Enable COP SR TouchScr	When set to ON, COP will use Smartrise TouchScreen protocol.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0322	Enable CE Elite COP	When set to ON, COP will use CE Elite TouchScreen COP.	0	1	0
01-0330	Third Valve Board	(Hydro Only) When set to ON at startup, the car will check for a Third valve board which only if the secondary valve board is enabled.	0	1	config
01-0331	Third SS	(Hydro Only) When set to ON, the system will look for Third soft starter signals if the secondary soft starter is enabled.	0	1	config
01-0337	Emotive Swap Indep.Service And Inspection	When set to ON, Emotive will swap the independent service mode and inspection mode display	0	1	0
01-0339	Support the collapsible type on CT Inspection	NA	0	1	0
01-0346	Enable Smartrise PI	When enabled, SRPI is enabled, and CE is disabled	0	1	0
01-0348	Always Monitor Soft Starter Fault	When set on, the fault received from SoftStarter will stop the car regardless SM state	0	1	0
01-0351	Fourth Valve Board	(Hydro Only) When set to ON at startup, the car will check for a Fourth valve board which only if the third valve board is enabled.	0	1	config
01-0353	UM Redundancy Bypass	Bypass uninenteded movement redundancy with CPLD	0	1	0
08-0048	Time Violation Rate	Sets the tolerance for module run time. Units are in 1% of run period	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0049	Acceptance ETSL Point	Sets the testing point for ETSL acceptance test. Zero is farthest from the terminal while seven is the closest to the terminal.	0	7	0
08-0051	VIP CarCall Timer (1s)	Sets the time in seconds allowed to place a car call after entering VIP mode with the doors fully open.	5	255	5
08-0052	Viscosity_CyclesAllowed	(Hydro Only) This counter limits the number of times the controller cycles through the viscosity run and viscosity rest stages before shutting down. This is to address the potential for a bad sensor or input. This setting is limited to 5 cycles.	0	5	5
08-0053	Viscosity_RunTime_1min	(Hydro Only) An extended version of the motor limit timer that is used when the car is on cold oil (Viscosity) operation. This timer limits the amount of time the pump motor can be on straight.	0	15	15
08-0054	Viscosity_RestTime_1min	(Hydro Only) This timer controls how long the motor sits at rest after the Viscosity_RunTime_1min has expired. This is set to a minimum of 5 minutes to prevent overheating the oil.	5	255	10
08-0055	JackResync_Frequency_1hr	(Hydro Only) Specifies how frequently to perform a jack resync. This option overrides JackResync_StartTime_15min.	0	255	0
08-0057	JackResync_Duration_1s	(Hydro Only) Specifies how long the car shall remain in the pit during jack resync. Units are in 1 second counts.	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0058	SAFE Pick Delay 50ms	(Hydro Only) When moving up, this is the delay between activating the MR SRU SAFE output and activating the primary start motor output. When moving down, this is the delay between activating the SAFE output and activating a valve. Units are in 50ms counts.	0	255	5
08-0059	SM1 Pick Delay 50ms	(Hydro Only) When moving up, this is the delay between activating the primary start motor output and activating a valve. Skipped if not moving up. Units are in 50ms counts.	0	255	10
08-0060	SM2 Pick Delay 50ms	(Hydro Only) If SecondarySoftStarter (01-0261) is ON, this is the delay between activating the secondary start motor output and activating the primary start motor output. Skipped if not moving up. If SecondarySoftStarter is OFF, this delay is skipped. Units are in 50ms counts.	0	255	0
08-0061	Pump Off Delay 50ms	(Hydro Only) Sets the time between deactivating the valves and turning off the start pump motor outputs. Skipped if not moving up. Units are in 50ms counts.	0	255	5
08-0062	SAFE Drop Delay 50ms	(Hydro Only) Sets the time between deactivating pump motor and turning off the MR SRU SAFE output. If the car is moving down this is the time between deactivating the valves and turning off the SAFE output. Units are in 50ms counts.	0	255	20

Number	String	Description	Min Value	Max Value	Default Value
08-0063	Delta Pick Delay (50ms)	(Hydro Only) This is the delay between activating the Delta output and activating the valve outputs. Skipped if not moving up. When set to 0, this step is skipped. This should only be set nonzero for a Wye Delta starter configuration.	0	255	config
08-0093	Car Stability Delay (50ms)	Sets the amount of time the car must be stable (moving at 1 fpm or less) before it's allowed to perform a non-releveling run. This timer can be helpful if a car bounces due to rope stretch. Units are in 50 ms counts.	0	255	0
08-0115	Fan And Light Timer	Sets the time the car may be idle before its fan and light output is turned off. If a longer timer is needed, the extended fan and light timer (08-184) should be used with the output MR Fan instead. Units are in seconds.	0	255	0
08-0116	Inspection OVSP Debounce Limit	Sets the time the car must be in an inspection overspeed state before a fault (F66) is flagged. The units are in 10 ms counts.	0	100	10
08-0117	DR Open OVSP Debounce Limit	Sets the time the car must be in a door open overspeed state before a fault (F67 to F74) is flagged. The units are in 10 ms counts.	0	100	10
08-0118	ETS OVSP Debounce Limit	Sets the time the car must be in an ETS overspeed state before a fault (F681 to F696) is flagged. The units are in 10 ms counts.	0	100	10

Number	String	Description	Min Value	Max Value	Default Value
08-0119	SFP Debounce Limit	Sets the time that the SFP relay must be seen low before a fault (F52) is flagged. The units are in 10 ms counts.	10	255	10
08-0120	Rate To Send Parameters	Sets the rate parameter update packets is sent on the group network. The units are in 5 ms counts.	0	255	20
08-0124	OfflineCtrlTi mer	Sets the minimum rate at which packets are sent from each of the main system processors	100	255	100
08-0131	Max Runtime (1s)	(Traction Only) Sets the max straight run time allowed in automatic operation before the car faults (F116). If set to zero, this fault is suppressed. Units are in seconds. (Hydro Only) This timer monitors the Start Motor (SM) output and will issue a MLT fault when the timer expires, the car should return to the bottom landing and go OOS with doors open. This is bypassed during construction and inspection operations. A different timer is used during viscosity operation. The if the timer expires when low pressure is active, the car faults and goes out of service until the low-pressure fault is cleared.	0	255	180
08-0137	Timeout Lock and CAM (100ms)	Sets the timeout which accounts for the delay between CAM activation and locks being made for manual doors. The units are in 100 ms counts. If set to zero, value defaults to 4 seconds.	0	255	40

Number	String	Description	Min Value	Max Value	Default Value
08-0138	AccessCode CCB Time (1s)	Sets the time the user must enter each CCB for access code. This timer will reset every time the user enters a CCB for access code.	0	255	5
08-0140	Releveling Delay (50ms)	Sets a delay before performing releveling. This timer can be helpful if a car bounces due to rope stretch. Units are in 50 ms counts.	0	255	10
08-0142	NumResend RunLog	Sets the number of times to resend each run log packet	0	255	10
08-0151	Time Violation Module	Sets which module to check against the 16–924-time violation setting. If set to zero, all modules are checked.	0	255	0
08-0152	MedValveSp eed (fpm)	(Hydro Only) Sets the estimated max medium valve speed.	0	255	0
08-0153	LowValveSpe ed (fpm)	(Hydro Only) Sets the estimated max low valve speed.	0	255	0
08-0160	HourlyFaultLi mit	Sets the number faults allowed within a one-hour window before the car goes out of service. If the car goes out of service, it remains out of service until the hour window elapses.	5	255	10
08-0173	CPLD Offline Timeout 10ms	Sets the timeout used when the CPLD offline alarms are enabled (01-135). Units are in 10 millisecond counts.	5	255	50
08-0184	MR Fan Timer (min)	Sets the time the car may be idle before its machine room fan output is turned off. Units are in minutes.	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0188	DSD Pretorque Delay (50ms)	Sets the pretorque assertion time prior to the start sequence. Only valid if DSD extended pretorque option is set (01-117). If set to zero, the value defaults to 200 ms.	0	255	4
08-0190	CCB Recent Press Timer (100ms)	Sets the time the lamp output is lit after a car call button is pressed	0	255	2
08-0194	Motion Direction Stage Plus1	When zero, direction is asserted during the accel delay start sequence stage. Otherwise, motion direction is asserted based on the start sequence enumeration en_motion_start_sequence plus 1.	0	255	0
08-0196	Max Starts Per Minute	Specifies how many times the car may attempt to start a run in Automatic operation during a 1-minute window. If the controller attempts additional runs, the car goes out of service until the real-time clock increments to the next minute. Set this parameter to zero to disable the feature.	0	255	10
08-0227	SS Vmax VAC %	(Hydro Only) Used for the C4 serial soft starter. Sets the percentage of input AC voltage used for ramp up.	10	90	config
08-0228	SS OVC (A)	(Hydro Only) Used for the C4 serial soft starter. Sets the overcurrent limit in amps.	1	140	config
08-0235	SS2 Ramp Up Time 100ms	(Hydro Only) Used for the C4 serial secondary soft starter. Sets the time to ramp up to V-Max.	0	250	config

Number	String	Description	Min Value	Max Value	Default Value
08-0236	SS2 Vmax VAC %	(Hydro Only) Used for the C4 serial secondary soft starter. Sets the percentage of input AC voltage used for ramp up.	10	90	config
08-0237	SS2 OVC (A)	(Hydro Only) Used for the C4 serial secondary soft starter. Sets the overcurrent limit in amps.	1	140	config
08-0241	Valve Type	(Hydro Only) This parameter enables the system as a hydro controller. It also selects which valve type is used. Types: - 0 = Traction - 1 = C4 Valve - 2 = Blain Valve - 3 = Bucher Valve Must be set at startup.	0	255	config
08-0245	Group Number	Sets the group number. This value is zero -based.	0	7	config
08-0248	AccelDelayR LVL 10ms	Sets the start of run delay between energizing the motor and commanding nonzero speed. This timer is used when starting a releveling run. This timer is set in 10 millisecond counts.	0	255	40
08-0252	HA Access Slide Distance 1in	This is the distance added to parameter 08-0110 and 08-0094 that a car is allowed to be within from the Top/Bottom DZ limit when traveling towards the respective terminal.	1	255	6
08-0255	DIP Bank to Override	Use this parameter to override a specific DIPA Bank. Disabled by default, zero. If not zero, 1 - MR_BANKA, 2 - CT_BANKA, 3 - COP_BANKA.	0	255	0

Number	String	Description	Min Value	Max Value	Default Value
08-0256	DIP Bank Bitmask	If DIP_Bank_Override is not zero, the specific DIP bank will be ignored, using this parameter as logical DIP bank.	0	255	0
08-0257	Discrete PI Timeout	Timeout in seconds to stop updating the discrete PI board. Discrete Board will timeout after 2 seconds and revert to default outputs.	0	255	0
08-0259	Jack Resync Day Of Week	(Hydro Only) Specifies what Day of the week (Monday-Sunday) to perform jack resync.	0	255	0
08-0267	Num Active Valves On Releveling	Sets the number of Valves/Soft Starters activated when the motion state is releveling. 0 means all valves shall be activated during releveling.	0	3	0
16-0849	SS OVT (F)	(Hydro Only) Used for the C4 serial soft starter. Sets the over temperature limit in degrees Fahrenheit counts.	176	302	config
16-0850	SS2 OVT (F)	(Hydro Only) Used for the C4 serial secondary soft starter. Sets the over temperature limit in degrees Fahrenheit counts.	176	302	config
16-0876	LockClipTime (10 ms)	Sets the debounce for lock and Gate switch open faults when the car is outside of door zone (see F163, F164, F165, F166, F167, F168, F169, F170). When set to zero, this timer defaults to 500ms. Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	1	50	50

Number	String	Description	Min Value	Max Value	Default Value
16-0924	Module Time Violation (ms)	Any module that runs longer than this set value triggers an alarm	0	65535	0
16-0964	MED Valve Max Run Dist (in)	(Hydro Only) Sets the max run distance where medium valve speed run is selected. Longer run will use the next higher speed valve. When set to zero, the valve is disabled. Units are in inches.	0	65535	0
16-0965	LOW Valve Max Run Dist (in)	(Hydro Only) Sets the max run distance where low valve speed run is selected. Longer run will use the next higher speed valve. When set to zero, the valve is disabled. Units are in inches.	0	65535	0
16-0966	LEVEL Valve Max Run Dist (in)	(Hydro Only) Sets the max run distance where level valve speed run is allowed. Longer run will use the next higher speed valve. When set to zero, the valve is disabled. Units are in inches.	0	65535	6
16-1041	Battery Board Test Time Start	(Hydro Only) Sets the start time for checking the battery lowering device daily for proper charge. When set to 00:00 or 0, the feature is disabled.	0	65535	0
16-1043	Jack Resync Time	(Hydro Only) Specifies the time in hour and minute the jack resync needs to be triggered. If 0 Jack Resync will be off.	0	65535	0
16-1044	Bypass GSW Check Distance	Distance from floor level in which GSW check is bypassed in manual doors. Units are in 0.019-inch counts.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-1045	Lockout Screen Code	This is the code required to enter to have access to the internal menu. When 0, the lockout feature is disabled.	0	9999	0
32-0007	Valves disable bitmap	The 32 bits are divided into 4 sets of 8 for each valve board, then each set is divided into 2 subsets of 4 for the High-Speed phase and the Leveling phase. Again, these are divided into the High-Speed valve and the Level Speed valve. Each Valve contains 2 bits, one for the corresponding Up direction, and the other for the Down direction. Assigning 0 to the bit will keep the normal behavior, while setting it to 1 will turn the valve off during the specified phase.	0	4294967295	0

25 MR Board Parameters

The table below lists the MR Board parameters.

Table 24: MR Board Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0124	IncreaseMRB SendRate	Doubles the minimum send rate of packets from the MRB processor to the reset of the car's main boards. This option is for test only and should remain OFF.	0	1	0
01-0126	ENA PreflightTest DIP	When set to ON, turning on MR board DIP 7B triggers a preflight check.	0	1	0
01-0137	ENA OldFRAM	When set to ON, the MR board is configured to work with old FRAM hardware.	0	1	0
01-0354	Enable Postflight Only	When enabled, the preflight is always done after the travel	0	1	0
16-0000 through 16-0007	MR IN (1-8)	Set the MR board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0392 through 16-0399	MR OUT (1-8)	Assign MR board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

26 NTS Parameters

The table below lists the NTS parameters.

Table 25: NTS Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0063	DISA NTS Update	Disables updating of NTS points. Used for debugging purposes and should be turned on only to temporarily manually adjust NTS trip points.	0	1	0
01-0067	Invert NTS Stop	Changes machine room NTS output from active high to active low. Needed for KEB drives. This option is obsolete for newer hardware running CPLD v1.1 or CPLD 3.7 and newer. These versions of hardware should invert NTS via the MR SRU DIP B1 and should leave this parameter set to OFF.	0	1	config
01-0153	DISA NonTerminal NTS	When set to OFF, during an NTS trip, the car stops at the first door zone passed after reaching NTS speed. When set to ON, the car stops at its original destination.	0	1	1
01-0260	Hydro DISA NTS ALM	(Hydro Only) When set to ON, NTS trip alarms are suppressed.	0	1	0
08-0128	ETS Offset From NTS	(Traction Only) Sets the position offset from generated NTS trip points to applied to ETS trip points. Units are in 0.2-inch counts. (Hydro Only) Sets the position offset applied to the configured up slowdown positions when performing TSRD trip tests for the hydro controller.	0	255	10

Number	String	Description	Min Value	Max Value	Default Value
08-0139	NTS Debounce	Sets the time the car must be exceeding one of the eight NTS trip points before an NTS trip is flagged (A1 to A64). Units are in 25 ms counts.	0	255	10
16-0784	NTS VEL P1-0	The velocity threshold of the first (closest to the terminal) NTS trip P1-0 for the normal motion profile. This value is read only.	0	65535	0
16-0785 through 16-0791	NTS VEL P1-(1-7)	The velocity threshold of the NTS trip P1-(1-7) for the normal motion profile. This value is read only.	0	65535	0
16-0792 through 16-0799	NTS VEL P2-(0-7)	The velocity threshold of the NTS trip point P2-(0-7) for the inspection motion profile. This value is read only.	0	65535	0
16-0800 through 16-0807	NTS VEL P3-(0-7)	The velocity threshold of the NTS trip point P3-(0-7) for the emergency power motion profile. This value is read only.	0	65535	0
16-0808 through 16-0815	NTS VEL P4-(0-7)	The velocity threshold of the NTS trip point P4-(0-7) for the short motion profile. This value is read only.	0	65535	0
16-0816 through 16-0823	NTS POS P1-(0-7)	N/A	0	65535	0
16-0824 through 16-0831	NTS POS P2-(0-7)	N/A	0	65535	0
16-0832 through 16-0839	NTS POS P3-(0-7)	N/A	0	65535	0
16-0840 through 16-0847	NTS POS P4-(0-7)	N/A	0	65535	0

27 OOS Parameters

The table below lists the OOS parameters.

Table 26: OOS Parameters

Number	String	Description	Min Value	Max Value	Default Value
08-0254	Reset Service Code Nb of Trips	Number of hall call trips before asserting Reset Service Code	0	255	0
16-1042	Reset Service Code	Reset service code after number of HC trips exceeded	0	9999	0

28 Parking Parameters

The table below lists the Parking parameters.

Table 27: Parking Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0089	CustomMode ParkingEnabled	Configure custom mode to enable parking during test	0	1	0
01-0146	ENADynamicParking	When set to ON, the parking floor is determined dynamically based on hall call history.	0	1	0
01-0213 through 01-0220	Dynamic Parking DO (1-8)	Sets the parking with door open option for the priority (1-8) dynamic parking landing, where priority 1 is the highest priority. If set to 0, the car will park with the doors closed.	0	1	0
01-0263	ENAPeak Dispatch	when set to ON, Enables the Remote Peak Parking dispatching inputs (Up/Down/Lobby peak)	0	1	0
01-0293	Enable Cycle Doors When Park	When parameter is set, and the door state is closed while parking, the door will open before closing	0	1	0
01-0315	Parking by Proximity	TBD	0	1	0
08-0113	Parking FLR	Sets the parking floor that is used if the parking timer (08-114) is nonzero and dynamic parking is off (01-146). This value is zero-based, so the bottom most floor is zero.	0	255	0
08-0114	Parking Timer	Sets the time it takes before an idle car is parked. If set to zero, parking is disabled. Units are in seconds.	0	255	0
08-0215 through 08-0222	Dynamic Parking Landing (1- 8) Plus 1	Sets the priority (1-8) dynamic parking landing, where priority 1 is the highest priority. If set to 0, this option is disabled.	0	255	0

29 Riser Board Parameters

The table below lists the Riser Board parameters.

Table 28: Riser Board Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0060	ENA Riser Alarms	Enables system alarms used to signal Riser board errors	0	1	0
16-0040 through 16-0047	RIS1 IN (1-8)	Set the Riser1 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0048 through 16-0055	RIS2 IN (1-8)	Set the Riser2 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0056 through 16-0063	RIS3 IN (1-8)	Set the Riser3 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0
16-0064 through 16-0071	RIS4 IN (1-8)	Set the Riser4 board input terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP INPUTS. Only two instances of each function are permitted. Inputs can also be inverted via SETUP SETUP I/O INVERT INPUTS.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0432 through 16-0439	RIS1 OUT (1-8)	Set the Riser1 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0440 through 16-0447	RIS2 OUT (1-8)	Set the Riser2 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0448 through 16-0455	RIS3 OUT (1-8)	Set the Riser3 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0
16-0456 through 16-0463	RIS4 OUT (1-8)	Set the Riser4 board output terminal (1-8) functionality. Change via SETUP SETUP I/O SETUP OUTPUTS. Only two instances of each function are permitted.	0	65535	0

30 Sabbath Parameters

The table below lists the Sabbath parameters.

Table 29: Sabbath Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0139	Sabbath Key Only ENA	When set to ON, Sabbath operations are only activated by Keyswitch input.	0	1	0
01-0140	Sabbath KeyOrTimer ENA	When set to ON, Sabbath operation is activated by either Keyswitch input or configured Sabbath Start Time (24-193) and Sabbath End Time (24-194)	0	1	0
01-0141	Sabbath Timer Only ENA	When set to ON, Sabbath operation is activated only by the configured Sabbath Start Time (24-193) and Sabbath End Time (24-194).	0	1	0
01-0197	DISA Sabbath Releveling	When set to ON, releveling is disabled when on Sabbath operation.	0	1	0
01-0223	Sabbath Disable LWD	When set ON, sabbath mode neutralizes LWD.	0	1	0
01-0234	Sabbath ENA Ext Buzzer	When set to ON, the Sabbath closing buzzer on time, if enabled via the SabbathClosingBuzzer_100ms (08-0015), is extended from when the doors start to close to when the doors are fully closed.	0	1	0
01-0242	Sabbath Nudge Doors	When set to ON, doors Nudge instead of close during Sabbath.	0	1	1

Number	String	Description	Min Value	Max Value	Default Value
08-0015	Sabbath Closing Buzzer 100ms	Sets the amount of time before doors begin to close that the door close buzzer is turned ON during Sabbath Mode. This buzzer output remains on until doors are fully closed. If set to zero, this feature is disabled.	0	255	50
24-0193	Sabbath_Start_Time	Sets the Friday start time for Sabbath when timer enable is set. Format is HHMM, for example, 12:34 PM is 1234.	0	16777215	0
24-0194	Sabbath_End_Time	Sets the Saturday end time for Sabbath when timer enable is set. Format is HHMM, for example, 12:34 PM is 1234.	0	16777215	0
32-0023	Sabbath Up Destinations 0	Sets which floors to stop at during Sabbath up destinations 1-32.	0	4294967295	config
32-0024	Sabbath Up Destinations 1	Sets which floors to stop at during Sabbath up destinations 33-64.	0	4294967295	config
32-0025	Sabbath Up Destinations 2	Sets which floors to stop at during Sabbath up destinations 65-96.	0	4294967295	config
32-0026	Sabbath Down Destinations 0	Sets which floors to stop at during Sabbath down destinations 1-32.	0	4294967295	config
32-0027	Sabbath Down Destinations 1	Sets which floors to stop at during Sabbath down destinations 33-64.	0	4294967295	config
32-0028	Sabbath Down Destinations 2	Sets which floors to stop at during Sabbath down destinations 65-96.	0	4294967295	config
32-0036	Sabbath Front Opening 0	Floors 1 to 32 front openings when in Sabbath operation.	0	4294967295	config

Number	String	Description	Min Value	Max Value	Default Value
32-0037	Sabbath Front Opening 1	Floors 33 to 64 front openings when in Sabbath operation.	0	4294967295	config
32-0038	Sabbath Front Opening 2	Floors 65 to 96 front openings when in Sabbath operation.	0	4294967295	config
32-0039	Sabbath Rear Opening 0	Floors 1 to 32 rear openings when in Sabbath operation.	0	4294967295	config
32-0040	Sabbath Rear Opening 1	Floors 33 to 64 rear openings when in Sabbath operation.	0	4294967295	config
32-0041	Sabbath Rear Opening 2	Floors 65 to 96 rear openings when in Sabbath operation.	0	4294967295	config

31 S-Curve Parameters

The table below lists the S-Curve parameters.

Table 30: S-Curve Parameters

Number	String	Description	Min Value	Max Value	Default Value
08-0017	Normal Accel	Sets the max acceleration rate used on normal profile runs. The normal profile is selected in all automatic operation runs longer than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second squared counts.	10	80	20
08-0018	Normal Jerk In Accel	Sets starting rate of acceleration change on normal profile runs. The normal profile is selected in all automatic operation runs longer than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second cubed counts.	3	250	20
08-0019	Normal Jerk Out Accel	Sets the rate of acceleration change when approaching max speed on normal profile runs. The normal profile is selected in all automatic operation runs longer than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second cubed counts.	3	250	20
08-0020	Normal Decel	Sets the max deceleration rate used on normal profile runs. The normal profile is selected in all automatic operation runs longer than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second squared counts.	10	80	10

Number	String	Description	Min Value	Max Value	Default Value
08-0021	Normal Jerk In Decel	Sets the starting rate of deceleration change on normal profile runs. The normal profile is selected in all automatic operation runs longer than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second cubed counts.	3	250	20
08-0022	Normal Jerk Out Decel	Sets the rate of deceleration change at the end of deceleration on normal profile runs. The normal profile is selected in all automatic operation runs longer than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second cubed counts.	3	250	8
08-0023	Quick Stop Decel	Sets the rate of deceleration used during an NTS trip. During an NTS trip, the drive ignores the controller's commanded speed and both ramp down their speeds independently.	0	255	30

Number	String	Description	Min Value	Max Value	Default Value
08-0024	P1 Leveling Distance 5mm	(Traction Only) Sets the distance from a floor at which the car transition to leveling speed (16-908) while on normal profile runs. The normal profile is selected in all automatic operation runs longer than minimum short profile distance (08-147), with exception of emergency power. When zero, the car does not transition to leveling speed. Units are in 0.2-inch counts. (Hydro Only) Adds leveling distance to the learned slowdown trip points in the up direction, extending the time the car will run a leveling speed before reaching a floor. Units are in 0.2-inch counts.	0	122	5
08-0025	Insp. Accel	Sets the max acceleration rate used on inspection profile runs. The inspection profile is selected while in inspection mode. Units are in 0.1 feet per second squared counts.	10	80	20
08-0026	Insp. Jerk In Accel	Sets starting rate of acceleration change on inspection profile runs. The inspection profile is selected while in inspection mode. Units are in 0.1 feet per second cubed counts.	3	250	20
08-0027	Insp. Jerk Out Accel	Sets the rate of acceleration change when approaching max speed on inspection profile runs. The inspection profile is selected while in inspection mode. Units are in 0.1 feet per second cubed counts.	3	250	20

Number	String	Description	Min Value	Max Value	Default Value
08-0028	Insp. Decel	Sets the max deceleration rate used on inspection profile runs. The inspection profile is selected while in inspection mode. Units are in 0.1 feet per second squared counts.	10	160	10
08-0029	Insp. Jerk Out Decel	This option is not used.	3	250	8
08-0030	Insp. Jerk In Decel	This option is not used.	3	250	60
08-0031	Insp. Leveling Distance	This option is not used. (Hydro only) This value adds/subtracts a distance from the learned position, if the car is traveling in the Up direction to adjust the floor level by few inches. Units are in 0.2 inch counts.	0	122	5
08-0032	EP Accel	Sets the max acceleration rate used on E-Power profile runs. The E-Power profile is selected when in emergency power mode. Units are in 0.1 feet per second squared counts. Note, this profile takes effect when the car is running on generator or battery power.	10	80	20
08-0033	EP Jerk In Accel	Sets starting rate of acceleration change on E-Power profile runs. The E-Power profile is selected when in emergency power mode. Units are in 0.1 feet per second cubed counts. Note, this profile takes effect when the car is running on generator or battery power.	3	250	20

Number	String	Description	Min Value	Max Value	Default Value
08-0034	EP Jerk Out Accel	Sets the rate of acceleration change when approaching max speed on E-Power profile runs. The E-Power profile is selected when in emergency power mode. Units are in 0.1 feet per second cubed counts. Note, this profile takes effect when the car is running on generator or battery power.	3	250	20
08-0035	EP Decel	Sets the max deceleration rate used on E-Power profile runs. The E-Power profile is selected when in emergency power mode. Units are in 0.1 feet per second squared counts. Note, this profile takes effect when the car is running on generator or battery power.	10	80	10
08-0036	EP Jerk In Decel	Sets the starting rate of deceleration change on E-Power profile runs. The E-Power run is used when on emergency power mode. Units are in 0.1 feet per second cubed counts. Note, this profile takes effect when the car is running on generator or battery power.	3	250	20
08-0037	EP Jerk Out Decel	Sets the rate of deceleration change at the end of deceleration on E-Power profile runs. The E-Power run is used when on emergency power mode. Units are in 0.1 feet per second cubed counts. Note, this profile takes effect when the car is running on generator or battery power.	3	250	8

Number	String	Description	Min Value	Max Value	Default Value
08-0038	EP Leveling Distance	<p>(Traction Only) Sets the distance from a floor at which the car transitions to leveling speed (16-908) while on E-Power profile runs. The E-Power profile is selected when in emergency power mode. When zero, the car does not transition to leveling speed. Units are in 0.2-inch counts.</p> <p>(Hydro Only) Adds leveling distance to the learned slowdown trip points in the down direction, extending the time the car will run a leveling speed before reaching a floor. Units are in 0.2-inch counts. Note, this profile takes effect when the car is running on generator or battery power.</p>	0	122	5
08-0039	Short Accel	<p>Sets the max acceleration rate used on short profile runs. The short profile is selected in all automatic operation runs shorter than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second squared counts.</p>	10	80	20
08-0040	Short Jerk In Accel	<p>Sets starting rate of acceleration change on short profile runs. The short profile is selected in all automatic operation runs shorter than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second cubed counts.</p>	3	250	20

Number	String	Description	Min Value	Max Value	Default Value
08-0041	Short Jerk Out Accel	Sets the rate of acceleration change when approaching max speed on short profile runs. The short profile is selected in all automatic operation runs shorter than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second cubed counts.	3	250	20
08-0042	Short Decel	Sets the max deceleration rate used on short profile runs. The short profile is selected in all automatic operation runs shorter than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second squared counts.	10	80	10
08-0043	Short Jerk In Decel	Sets the rate of deceleration change when approaching a floor on short profile runs. The short profile is selected in all automatic operation runs shorter than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second cubed counts.	3	250	20
08-0044	Short Jerk Out Decel	Sets the rate of deceleration change at the end of deceleration on short profile runs. The short profile is selected in all automatic operation runs shorter than minimum short profile distance (08-147), with exception of emergency power. Units are in 0.1 feet per second cubed counts.	3	250	8

Number	String	Description	Min Value	Max Value	Default Value
08-0045	Short Leveling Distance	<p>(Traction only)Sets the distance from a floor at which the car transitions to leveling speed (16-908) while on short profile runs. The short profile is selected in all automatic operation runs shorter than minimum short profile distance (08-147), with exception of emergency power. When zero, the car will not transition to leveling speed. Units are in 0.2 inch counts.</p> <p>(Hydro only) This value adds/subtracts a distance from the learned position, if the car is traveling in the Down direction to adjust the floor level by few inches.Units are in 0.2 inch counts.</p>	0	122	5
08-0147	Short Profile Minimum Distance	Sets the distance below which the Short Motion profile is used instead of the Normal Motion profile. Units are in feet.	0	255	0
16-0897	Soft Limit Distance Up (ft)	Sets the distance away from the top terminal floor that the car switches to inspection terminal speed (16-875) during manual operation	0	65535	2
16-0898	Soft Limit Distance Down (ft)	Sets the distance away from the bottom terminal floor that the car switches to inspection terminal speed (16-875) during manual operation	0	65535	2

32 Security Parameters

The table below lists the Security parameters.

Table 31: Security Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0021	Enable CC Secured Alarms	When set to ON, if a pressed CCB is secured, the CCB Secured alarm will be asserted.	0	1	1
01-0065	Independent Srv. Byp. Security	Ignores car call security when on independent service	0	1	0
01-0086	Custom Mode IgnoreCar Call Security	Configure custom mode to ignore all security car calls during test	0	1	0
01-0087	Custom Mode IgnoreHall Call Security	Configure custom mode to ignore all security hall calls during test	0	1	0
01-0138	ENA Hall Security	Enables hall call security	0	1	0
01-0192	ENA Check In Floor	Enables Check In Security	0	1	0
01-0196	Access Code follows Time Security	When set to ON, floors that are secured by an Access Code will only require a code if the time is within the valid time set for Time Security. If an invalid time is set (as in no time is set or time frame is set up wrong), Access Code will be bypassed. When set to OFF, access code is always required regardless of time, for opening where they are configured.	0	1	0
01-0257	ENA Remote Security	When set to ON, remote monitoring systems can enable car call and hall call security at different openings.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0272	ENA HC SEC BY CAR	"When set to OFF, the hall call security configuration on the master car is applied to all group cars. On hall call button press, hall security is evaluated before the call is latched. Latched calls are not reassessed if the call is secured after it is latched. By default this option should be OFF.			ENA HC SEC BY CAR
16-0928	Front Check In Security 0	Front door check in security for floors 1 to 16.	0	65535	0
16-0929	Front Check In Security 1	Front door check in security for floors 17 to 32.	0	65535	0
16-0930	Front Check In Security 2	Front door check in security for floors 33 to 48.	0	65535	0
16-0931	Front Check In Security 3	Front door check in security for floors 49 to 64.	0	65535	0
16-0932	Front Check In Security 4	Front door check in security for floors 65 to 80.	0	65535	0
16-0933	Front Check In Security 5	Front door check in security for floors 81 to 96.	0	65535	0
16-0934	Rear Check In Security 0	Rear door check in security for floors 1 to 16.	0	65535	0
16-0935	Rear Check In Security 1	Rear door check in security for floors 17 to 32.	0	65535	0
16-0936	Rear Check In Security 2	Rear door check in security for floors 33 to 48.	0	65535	0
16-0937	Rear Check In Security 3	Rear door check in security for floors 49 to 64.	0	65535	0
16-0938	Rear Check In Security 4	Rear door check in security for floors 65 to 80.	0	65535	0
16-0939	Rear Check In Security 5	Rear door check in security for floors 81 to 96.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0940	Hall Secure Map F 0	Hall call security map for front openings. Turns on hall call security for front openings on group landings 1 to 16. Edit via SETUP GROUP SETUP HALL SECURITY MAP (F). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config
16-0941	Hall Secure Map F 1	Hall call security map for front openings. Turns on hall call security for front openings on group landings 17 to 32. Edit via SETUP GROUP SETUP HALL SECURITY MAP (F). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-0942	Hall Secure Map F 2	Hall call security map for front openings. Turns on hall call security for front openings on group landings 33 to 48. Edit via SETUP GROUP SETUP HALL SECURITY MAP (F). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config
16-0943	Hall Secure Map F 3	Hall call security map for front openings. Turns on hall call security for front openings on group landings 49 to 64. Edit via SETUP GROUP SETUP HALL SECURITY MAP (F). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-0944	Hall Secure Map F 4	Hall call security map for front openings. Turns on hall call security for front openings on group landings 65 to 80. Edit via SETUP GROUP SETUP HALL SECURITY MAP (F). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config
16-0945	Hall Secure Map F 5	Hall call security map for front openings. Turns on hall call security for front openings on group landings 81 to 96. Edit via SETUP GROUP SETUP HALL SECURITY MAP (F). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config
16-0973	HC_Secure Timed BitmapF0	Hall call timed security map for front openings. Turns on hall call security for front openings on group landings 1 to 16	0	65535	0
16-0974	HC_Secure Timed BitmapF1	Hall call timed security map for front openings. Turns on hall call security for front openings on group landings 17 to 32	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-0975	HC_Secure Timed BitmapF2	Hall call timed security map for front openings. Turns on hall call security for front openings on group landings 33 to 48	0	65535	0
16-0976	HC_Secure Timed BitmapF3	Hall call timed security map for front openings. Turns on hall call security for front openings on group landings 49 to 64	0	65535	0
16-0977	HC_Secure Timed BitmapF4	Hall call timed security map for front openings. Turns on hall call security for front openings on group landings 65 to 80	0	65535	0
16-0978	HC_Secure Timed BitmapF5	Hall call timed security map for front openings. Turns on hall call security for front openings on group landings 81 to 96	0	65535	0
16-0979	Weekday Start Time for Timed HC Security	Sets the Weekday Start Time for Timed Hall call Security.	0	65535	0
16-0980	Weekday End Time for Timed HC Security	Sets the Weekday End Time for Timed Hall Call Security.	0	65535	0
16-0981	Weekend Start Time for Timed HC Security	Sets the Weekend Start Time for Timed Hall Call Security.	0	65535	0
16-0982	Weekend End Time for Timed HC Security	Sets the Weekend End Time for Timed Hall Call Security.	0	65535	0
16-0999	Weekday Start Time for Timed CC Security	Sets the Weekday Start Time for Timed Car Call Security.	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-1000	Weekday End Time for Timed CC Security	Sets the Weekday End Time for Timed Car Call Security.	0	65535	0
16-1001	Weekend Start Time for Timed CC Security	Sets the Weekend Start Time for Timed Car Call Security.	0	65535	0
16-1002	Weekend End Time for Timed CC Security	Sets the Weekend End Time for Timed Car Call Security.	0	65535	0
16-1010	HC_Secure Timed BitmapR0	Hall call timed security map for rear openings. Turns on hall call security for rear openings on group landings 1 to 16	0	65535	0
16-1011	HC_Secure Timed BitmapR1	Hall call timed security map for rear openings. Turns on hall call security for rear openings on group landings 17 to 32	0	65535	0
16-1012	HC_Secure Timed BitmapR2	Hall call timed security map for rear openings. Turns on hall call security for rear openings on group landings 33 to 48	0	65535	0
16-1013	HC_Secure Timed BitmapR3	Hall call timed security map for rear openings. Turns on hall call security for rear openings on group landings 49 to 64	0	65535	0
16-1014	HC_Secure Timed BitmapR4	Hall call timed security map for rear openings. Turns on hall call security for rear openings on group landings 65 to 80	0	65535	0
16-1015	HC_Secure Timed BitmapR5	Hall call timed security map for rear openings. Turns on hall call security for rear openings on group landings 81 to 96	0	65535	0

Number	String	Description	Min Value	Max Value	Default Value
16-1035	Hall Secure Map R 0	Hall call security map for rear openings. Turns on hall call security for rear openings on group landings 1 to 16. Edit via SETUP GROUP SETUP HALL SECURITY MAP (R). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config
16-1036	Hall Secure Map R 1	Hall call security map for rear openings. Turns on hall call security for rear openings on group landings 17 to 32. Edit via SETUP GROUP SETUP HALL SECURITY MAP (R). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-1037	Hall Secure Map R 2	Hall call security map for rear openings. Turns on hall call security for rear openings on group landings 33 to 48. Edit via SETUP GROUP SETUP HALL SECURITY MAP (R). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config
16-1038	Hall Secure Map R 3	Hall call security map for rear openings. Turns on hall call security for rear openings on group landings 49 to 64. Edit via SETUP GROUP SETUP HALL SECURITY MAP (R). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-1039	Hall Secure Map R 4	Hall call security map for rear openings. Turns on hall call security for rear openings on group landings 65 to 80. Edit via SETUP GROUP SETUP HALL SECURITY MAP (R). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config
16-1040	Hall Secure Map R 5	Hall call security map for rear openings. Turns on hall call security for rear openings on group landings 81 to 96. Edit via SETUP GROUP SETUP HALL SECURITY MAP (R). Which hall board function ranges are affected by this mask is set by the Hall Security Mask (08-0208). This should be set the same on all group cars. If EnableHCSecurityByCar (01-0272) is ON, this parameter is car specific instead of shared group wide.	0	65535	config
24-0195	Job ID	N/A	0	16777215	config
24-0196	Payment Passcode	N/A	0	16777215	0
32-0008	Front Security Map 0	Front door car call security map for floors 1 to 32. Edit via SETUP FLOORS SECURITY (F).	0	4294967295	Job Specific

Number	String	Description	Min Value	Max Value	Default Value
32-0009	Front Security Map 1	Front door car call security map for floors 33 to 64. Edit via SETUP FLOORS SECURITY (F).	0	4294967295	config
32-0010	Front Security Map 2	Front door car call security map for floors 65 to 96. Edit via SETUP FLOORS SECURITY (F).	0	4294967295	config
32-0012	Rear Security Map 0	Rear door car call security map for floors 1 to 32. Edit via SETUP FLOORS SECURITY (R).	0	4294967295	config
32-0013	Rear Security Map 1	Rear door car call security map for floors 33 to 64. Edit via SETUP FLOORS SECURITY (R).	0	4294967295	config
32-0014	Rear Security Map 2	Rear door car call security map for floors 65 to 96. Edit via SETUP FLOORS SECURITY (R).	0	4294967295	config
32-0016	Secure Timed BitmapF 0	Front door car call timed security map for floors 1 to 32. Edit via SETUP FLOORS Timed CC security Enable Floor (F)	0	4294967295	config
32-0017	Secure Timed BitmapF 1	Front door car call timed security map for floors 33 to 64. Edit via SETUP FLOORS Timed CC security Enable Floor (F)	0	4294967295	config
32-0018	Secure Timed BitmapF 2	Front door car call timed security map for floors 65 to 96. Edit via SETUP FLOORS Timed CC security Enable Floor (F)	0	4294967295	config
32-0020	Secure Timed BitmapR 0	Rear door car call timed security map for floors 1 to 32. Edit via SETUP FLOORS Timed CC security Enable Floor (R)	0	4294967295	config

Number	String	Description	Min Value	Max Value	Default Value
32-0021	Secure Timed BitmapR 1	Rear door car call timed security map for floors 33 to 64. Edit via SETUP FLOORS Timed CC security Enable Floor (R)	0	4294967295	config
32-0022	Secure Timed BitmapR 2	Rear door car call timed security map for floors 65 to 96. Edit via SETUP FLOORS Timed CC security Enable Floor (R)	0	4294967295	config

33 Speed Parameters

The table below lists the Speed parameters.

Table 32: Speed Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0039	Improved Max SPD	When set to ON, a run's peak speed is checked in 5% steps instead of 10%. This along with turning off (01-174) makes the peak run speeds closer to the theoretical peak speed for the given S-Curve settings.	0	1	0
01-0069	ENA SPD Dev Control	Enables smoothing of the speed command pattern. This option should be left ON and is for test purposes only.	0	1	1
01-0073	DISA Construction OVSP	Disables the construction overspeed fault (F255)	0	1	1
01-0174	Reduced Max SPD	When set to ON, max run speed calculations are estimated based on 115% of the expected required run distance instead of 105%.	0	1	0
01-0253	Learn_Slowdowns	(Hydro Only) When set to ON, putting the car on learn by turning ON MR DIP A5 will prepare the car for a slowdown learn, instead of the usual hoistway learn. Holding down the MR UP or MR DOWN button until contract speed is reached will cause the car to capture its slowdown points. This process needs to be performed in both the up and down directions.	0	1	0

Number	String	Description	Min Value	Max Value	Default Value
01-0271	ENA FIXED RLVL	When set to ON, the car's releveling runs will skip the standard S-Curve control and instead command a fixed speed throughout the releveling run. This fixed speed is MinRelevelSpeed (08-0195).	0	1	0
01-0283	Bypass Term Ignores Term Spd	When set to ON, while on Inspection, if Bypass Term Limit is turned ON, as the car approaches the soft limit distance of either terminal, terminal spd will be ignored and the controller will continue to command the inspection speed.	0	1	1
01-0301	Enable Adaptive Slowdown Learning	Hydro: Turn on to adjust the slowdown distances to achieve a target leveling time. (08-0263) - Slowdown_TargetLevelTime_100ms	0	1	0
01-0302	Enable Hydro Movement Test	Hydro: Enable a test to detect zero movement when a movement valve is active. "Speed Dev" F9 when detected and car should be moving.	0	1	1
08-0046	Leveling Decel 01fps	Sets the rate of decel from leveling speed. Units are in 0.1 feet per second squared.	20	255	255
08-0047	NTSD Speed	Sets the target speed used during a NTS trip. Units are in feet per minute.	1	20	10
08-0136	General OVSP Debounce Limit	Sets the time the car must be in a general overspeed state before a fault (F64) is flagged. The units are in 10 ms counts.	0	255	10
08-0143	Auto Rescue Spd (fpm)	Sets the max speed to use during auto rescue operation	0	255	config

Number	String	Description	Min Value	Max Value	Default Value
08-0159	Construction OVSP Debounce	Sets the time the car must be in a construction overspeed state before a fault (F255) is flagged. The units are in 10 ms counts.	0	100	10
08-0182	ETSL OVSP Debounce Limit	Sets the time the car must be in an ETSL overspeed state before a fault (F697 to F712) is flagged. The units are in 10 ms counts.	0	255	10
08-0183	RatedBuffer Spd 10fpm	Sets the rated buffer speed. Used for checking reduced speed buffer faults (F677 to F680) which evaluate if ETSL points are placed far enough out to prevent striking the buffer above the rated speed. Units are in 10 fpm counts.	0	255	config
08-0195	Min Relevel Speed	Sets the minimum acceleration speed at the start of a releveling run.	0	255	1
08-0207	Access Speed (fpm)	Sets the speed used when in access mode. The controller faults if this is higher than 150 fpm.	0	150	20
08-0225	EQ Hoistway Scan Speed	Sets the speed used during EQ Hoistway Scan.	10	150	75
08-0226	SS Ramp Up Time 100ms	(Hydro Only) Used for the C4 serial soft starter. Sets the time to ramp up to V-Max.	0	250	config
08-0263	Target Leveling Time	Hydro: Target Leveling time for Adaptive Slowdown operation [01-0301 (Enable_AdaptiveSlowdown)]. 0.1 second increments. Default 2 seconds if not set.	0	255	20
16-0862	Acceptance A/D SPD	Sets the car speed for A/D overspeed acceptance testing	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-0864	Acceptance Buffer SPD	Sets the car speed for buffer acceptance testing. For Car buffer acceptance test in Hydro if this speed is equal to contract speed, the car will run with high valves active and if this speed is anything less than contract speed the car will run with level valve active.	0	65535	config
16-0872	Contract SPD	(Traction Only) Sets the max speed of the car. (Hydro Only) This sets the estimated max speed of the car when running with the high-speed valve. Requires system power cycle after changing to clear the "Need To Cycle Pwr" fault (F83/F717/F718).	10	1600	config
16-0873	Inspection SPD	Sets the speed used when in inspection mode, but not in access mode. The controller faults if this is higher than 150 fpm.	0	150	50
16-0874	Learn SPD	Sets the speed used when in learn mode. Controller faults if this is higher than contract speed.	0	1600	25
16-0875	Inspection Terminal SPD	Sets the speed the car uses while in inspection and within the configured soft limit distance (16-897 and 16-898) of a terminal floor	0	30	15
16-0877	Min Accel SPD	Sets the minimum commanded speed used during acceleration. Necessary for quick recovery from rollback and cases of limited drive control at low speeds.	1	25	1

Number	String	Description	Min Value	Max Value	Default Value
16-0878	EPower SPD fpm	Sets the speed the car uses while in emergency power mode. Set to 10 fpm at minimum.	0	65535	10
16-0902	SPD Dev Threshold	Sets the time speed deviation must be detected before a fault is set (F9). Not used in Hydro system.	0	65535	100
16-0903	SPD Dev Timeout (10 ms)	Sets the time speed deviation must be detected before a fault is set (F9) (Hydro) - Used to detect non-movement when a Valve is open. Set to 2-5.	0	65535	300
16-0904	SPD Dev Percent	Sets the percent difference between the command speed and the car speed required to trip a speed deviation fault (F9)	0	100	20
16-0905	Traction Loss Threshold	Sets the minimum car speed required for a traction loss fault (F7)	0	65535	100
16-0906	Traction Loss Timeout (10 ms)	Sets the time traction loss must be detected before a fault is set (F7)	0	65535	1000
16-0907	Traction Loss Percent	Sets the percent difference between the encoder speed and the car speed required to trip a traction loss fault (F7)	0	100	60
16-0908	Leveling SPD	Sets the speed used in automatic operation when leveling into a floor. If leveling distance is zero, the leveling speed has no effect. For the hydro controller only, this sets the estimated max speed the car will run at when the car is running with the leveling or releveling.	1	20	5

Number	String	Description	Min Value	Max Value	Default Value
16-0967	Speed1_THOLD_fpm	<p>(Hydro Only) Sets the speed threshold above which the Speed1_SlowdownDist_05mm is used. The positioning system speed feedback is used for this comparison. Units are in feet per minute.</p> <p>Speed1_THOLD_fpm should be the highest speed, with Speed2_THOLD_fpm through Speed6_THOLD_fpm should be decreasing in value.</p> <p>Recommended defaults = $(\text{ContractSpeed} / 7) * (7 - \#)$. Where # is the value found in, Speed#_THOLD_fpm. Setting the value to zero will disable this feature.</p>	0	65535	config
16-0968	Speed2_THOLD_fpm	<p>(Hydro Only) Sets the speed threshold above which the Speed2_SlowdownDist_05mm is used. The positioning system speed feedback is used for this comparison. Units are in feet per minute.</p> <p>Speed1_THOLD_fpm should be the highest speed, with Speed2_THOLD_fpm through Speed6_THOLD_fpm should be decreasing in value.</p> <p>Recommended defaults = $(\text{ContractSpeed} / 7) * (7 - \#)$. Where # is the value found in, Speed#_THOLD_fpm. Setting the value to zero will disable this feature.</p>	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-0969	Speed3_THOLD_fpm	<p>(Hydro Only) Sets the speed threshold above which the Speed3_SlowdownDist_05mm is used. The positioning system speed feedback is used for this comparison. Units are in feet per minute.</p> <p>Speed1_THOLD_fpm should be the highest speed, with Speed2_THOLD_fpm through Speed6_THOLD_fpm should be decreasing in value.</p> <p>Recommended defaults = $(\text{Contract Speed} / 7) * (7 - \#)$. Where # is the value found in, Speed#_THOLD_fpm. Setting the value to zero will disable this feature.</p>	0	65535	config
16-0970	Speed4_THOLD_fpm	<p>(Hydro Only) Sets the speed threshold above which the Speed4_SlowdownDist_05mm is used. The positioning system speed feedback is used for this comparison. Units are in feet per minute.</p> <p>Speed1_THOLD_fpm should be the highest speed, with Speed2_THOLD_fpm through Speed6_THOLD_fpm should be decreasing in value.</p> <p>Recommended defaults = $(\text{ContractSpeed} / 7) * (7 - \#)$. Where # is the value found in, Speed#_THOLD_fpm. Setting the value to zero will disable this feature.</p>	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-0971	Speed5_THOLD_fpm	<p>(Hydro Only) Sets the speed threshold above which the Speed5_SlowdownDist_05mm is used. The positioning system speed feedback is used for this comparison. Units are in feet per minute.</p> <p>Speed1_THOLD_fpm should be the highest speed, with Speed2_THOLD_fpm through Speed6_THOLD_fpm should be decreasing in value.</p> <p>Recommended defaults = $(\text{ContractSpeed} / 7) * (7 - \#)$. Where # is the value found in, Speed#_THOLD_fpm. Setting the value to zero will disable this feature.</p>	0	65535	config
16-0972	Speed6_THOLD_fpm	<p>(Hydro Only) Sets the speed threshold above which the Speed6_SlowdownDist_05mm is used. The positioning system speed feedback is used for this comparison. Units are in feet per minute.</p> <p>Speed1_THOLD_fpm should be the highest speed, with Speed2_THOLD_fpm through Speed6_THOLD_fpm should be decreasing in value.</p> <p>Recommended defaults = $(\text{ContractSpeed} / 7) * (7 - \#)$. Where # is the value found in, Speed#_THOLD_fpm. Setting the value to zero will disable this feature.</p>	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-1003	Speed1_ Slowdown Dist_ UP_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed1_THOLD_fpm. This distance applies when the car is moving in the up direction. Units are in 0.5 mm counts.	0	65535	3098
16-1004	Speed2_ Slowdown Dist_ UP_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed2_THOLD_fpm. This distance applies when the car is moving in the up direction. Units are in 0.5 mm counts.	0	65535	3098
16-1005	Speed3_ Slowdown Dist_ UP_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed3_THOLD_fpm. This distance applies when the car is moving in the up direction. Units are in 0.5 mm counts.	0	65535	3098
16-1006	Speed4_ Slowdown Dist_ UP_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed4_THOLD_fpm. This distance applies when the car is moving in the up direction. Units are in 0.5 mm counts.	0	65535	3098

Number	String	Description	Min Value	Max Value	Default Value
16-1007	Speed5_Slowdown Dist_UP_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed5_THOLD_fpm. This distance applies when the car is moving in the up direction. Units are in 0.5 mm counts.	0	65535	3098
16-1008	Speed6_Slowdown Dist_UP_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed6_THOLD_fpm. This distance applies when the car is moving in the up direction. Units are in 0.5 mm counts.	0	65535	3098
16-1009	Speed7_Slowdown Dist_UP_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed7_THOLD_fpm. This distance applies when the car is moving in the up direction. Units are in 0.5 mm counts.	0	65535	3098
16-1019	Speed1_Slowdown Dist_DN_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed1_THOLD_fpm. This distance applies when the car is moving in the down direction. Units are in 0.5 mm counts.	0	65535	3098

Number	String	Description	Min Value	Max Value	Default Value
16-1020	Speed2_Slowdown Dist_DN_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed2_THOLD_fpm. This distance applies when the car is moving in the down direction. Units are in 0.5 mm counts.	0	65535	3098
16-1021	Speed3_Slowdown Dist_DN_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed3_THOLD_fpm. This distance applies when the car is moving in the down direction. Units are in 0.5 mm counts.	0	65535	3098
16-1022	Speed4_Slowdown Dist_DN_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed4_THOLD_fpm. This distance applies when the car is moving in the down direction. Units are in 0.5 mm counts.	0	65535	3098
16-1023	Speed5_Slowdown Dist_DN_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed5_THOLD_fpm. This distance applies when the car is moving in the down direction. Units are in 0.5 mm counts.	0	65535	3098

Number	String	Description	Min Value	Max Value	Default Value
16-1024	Speed6_Slowdown Dist_DN_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed6_THOLD_fpm. This distance applies when the car is moving in the down direction. Units are in 0.5 mm counts.	0	65535	3098
16-1025	Speed7_Slowdown Dist_DN_05mm	(Hydro Only) Sets the distance from its destination where the car must cut its high-speed valves when moving at a speed above the Speed7_THOLD_fpm. This distance applies when the car is moving in the down direction. Units are in 0.5 mm counts.	0	65535	3098
16-1018	Slowdown Factor Up	(Hydro Only) Slowdown factor used to generate UP slowdown distances for the speed thresholds. Distance = $(\text{Speed_Threshold_fps} * \text{factor}) / 10$	0	1500	50
16-1034	Slowdown Factor Down	(Hydro Only) Slowdown factor used to generate DOWN slowdown distances for the speed thresholds. Distance = $(\text{Speed_Threshold_fps} * \text{factor}) / 10$	0	1500	50

34 Swing Mode Parameters

The table below lists the Swing Mode parameters.

Table 33: Swing Mode Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0082	Swing Calls ENA	Allows swing calls to activate swing operation	0	1	1
01-0083	Swing Stay In Group	When set to ON, the car stays in group during swing operation	0	1	0
01-0291	Answer Swing Calls on Normal	Answer swing calls when car is on Normal	0	1	0
08-0161	Swing IdleTime 1s	If Swing mode is entered by a button press, this timer specifies how long to remain in Swing operation once the car is idle.	0	255	10
16-0946	Swing Door Opening F 0	Set which front openings are manual swing hall doors for landing 1-16. When each bit is set ON, and when "Door Type Select Front" (08-0012) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0947	Swing Door Opening F 1	Set which front openings are manual swing hall doors for landing 17-32. When each bit is set ON, and when "Door Type Select Front" (08-0012) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0948	Swing Door Opening F 2	Set which front openings are manual swing hall doors for landing 33-48. When each bit is set ON, and when "Door Type Select Front" (08-0012) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-0949	Swing Door Opening F 3	Set which front openings are manual swing hall doors for landing 49-64. When each bit is set ON, and when "Door Type Select Front" (08-0012) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0950	Swing Door Opening F 4	Set which front openings are manual swing hall doors for landing 65-80. When each bit is set ON, and when "Door Type Select Front" (08-0012) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0951	Swing Door Opening F 5	Set which front openings are manual swing hall doors for landing 81-96. When each bit is set ON, and when "Door Type Select Front" (08-0012) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0952	Swing Door Opening R 0	Set which rear openings are manual swing hall doors for landing 1-16. When each bit is set ON, and when "Door Type Select Reart" (08-0013) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0953	Swing Door Opening R 1	Set which rear openings are manual swing hall doors for landing 17-32. When each bit is set ON, and when "Door Type Select Reart" (08-0013) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config

Number	String	Description	Min Value	Max Value	Default Value
16-0954	Swing Door Opening R 2	Set which rear openings are manual swing hall doors for landing 33-48. When each bit is set ON, and when "Door Type Select Reart" (08-0013) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0955	Swing Door Opening R 3	Set which rear openings are manual swing hall doors for landing 49-64. When each bit is set ON, and when "Door Type Select Reart" (08-0013) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0956	Swing Door Opening R 4	Set which rear openings are manual swing hall doors for landing 65-80. When each bit is set ON, and when "Door Type Select Reart" (08-0013) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config
16-0957	Swing Door Opening R 5	Set which rear openings are manual swing hall doors for landing 81-96. When each bit is set ON, and when "Door Type Select Reart" (08-0013) is set to SWING (3). When a bit is OFF, that opening is assumed to have automatic hall doors.	0	65535	config

35 XREG Parameters

The table below lists the XREG parameters.

Table 34: XREG Parameters

Number	String	Description	Min Value	Max Value	Default Value
01-0167	XREG ENA In Motion Assignment	When set to ON, XREG assignments can be made even when the car reports it is in motion. This can help increase XREG car utilization and compensate for errors seen when the intended XREG car does not take the assigned call.	0	1	1
01-0168	XREG Priority From Arrival Dir	When set to ON, XREG car's direction priority are read from their last arrival lantern signal. If set to OFF, direction priority is up for even car numbers and down for odd car numbers.	0	1	0
08-0167	Attendant Dispatch Timeout (1s)	Sets the time the car has to respond to a destination assignment when on attendant service before it temporarily removes itself from group and the call is be reassigned. This prevents excessive delays in answering hall calls due to someone holding open the car door. If either the dispatch timeout (08-175) or dispatch offline (08-176) are set to zero, this feature is disabled. Units are in 1 second counts.	10	255	60

Number	String	Description	Min Value	Max Value	Default Value
08-0175	Dispatch Timeout 1s	Sets the time the car has to respond to a destination assignment before it temporarily removes itself from group and the call is be reassigned. This prevents excessive delays in answering hall calls due to someone holding open the car door. If either the dispatch timeout (08-175) or dispatch offline (08-176) are set to zero, this feature is disabled. Units are in 1 second counts.	10	255	30
08-0176	Dispatch Offline 1s	Sets the time the car removes itself from the group after failing to take an assigned call. If either the dispatch timeout (08-175) or dispatch offline (08-176) are set to zero, this feature is disabled. Units are in 1 second counts.	0	255	10
08-0177	NumX RegCars	When set to zero, disables XREG (cross registration or alien) car dispatching. When set to nonzero, enables XREG dispatching.	0	8	0
08-0192	XREG Dest. Timeout (10s)	When nonzero, if an assigned XREG destination has not been cleared for the XREG Dest. Timeout (10s), the car is removed from group for the time set by XREG Dest. Offline (10s).	0	255	15
08-0193	XREG Dest. Offline (10s)	When nonzero, if an assigned XREG destination has not been cleared for the XREG Dest. Timeout (10s), the car is removed from group for the time set by XREG Dest. Offline (10s).	0	255	3

Number	String	Description	Min Value	Max Value	Default Value
08-0234	XREG RecallDelay	The estimated time an alien cross registration car will take to move to the recall floor on emergency power. Value is in 1 second counts.	0	255	30

Appendix – Conversion Chart

The table below lists the Conversion Chart.

Table 35: Conversion Chart

DEC	HEX	BIN
1	01	00000001
2	02	00000010
3	03	00000011
4	04	00000100
5	05	00000101
6	06	00000110
7	07	00000111
8	08	00001000
9	09	00001001
10	0A	00001010
11	0B	00001011
12	0C	00001100
13	0D	00001101
14	0E	00001110
15	0F	00001111
16	10	00010000
17	11	00010001
18	12	00010010
19	13	00010011
20	14	00010100
21	15	00010101
22	16	00010110
23	17	00010111
24	18	00011000
25	19	00011001
26	1A	00011010
27	1B	00011011
28	1C	00011100
29	1D	00011101
30	1E	00011110
31	1F	00011111
32	20	00100000
33	21	00100001
34	22	00100010
35	23	00100011
36	24	00100100
73	49	01001001

DEC	HEX	BIN
37	25	00100101
38	26	00100110
39	27	00100111
40	28	00101000
41	29	00101001
42	2A	00101010
43	2B	00101011
44	2C	00101100
45	2D	00101101
46	2E	00101110
47	2F	00101111
48	30	00110000
49	31	00110001
50	32	00110010
51	33	00110011
52	34	00110100
53	35	00110101
54	36	00110110
55	37	00110111
56	38	00111000
57	39	00111001
58	3A	00111010
59	3B	00111011
60	3C	00111100
61	3D	00111101
62	3E	00111110
63	3F	00111111
64	40	01000000
65	41	01000001
66	42	01000010
67	43	01000011
68	44	01000100
69	45	01000101
70	46	01000110
71	47	01000111
72	48	01001000
114	72	01110010

DEC	HEX	BIN
74	4A	01001010
75	4B	01001011
76	4C	01001100
77	4D	01001101
78	4E	01001110
79	4F	01001111
80	50	01010000
81	51	01010001
82	52	01010010
83	53	01010011
84	54	01010100
85	55	01010101
86	56	01010110
87	57	01010111
88	58	01011000
89	59	01011001
90	5A	01011010
91	5B	01011011
92	5C	01011100
93	5D	01011101
94	5E	01011110
95	5F	01011111
96	60	01100000
97	61	01100001
98	62	01100010
99	63	01100011
100	64	01100100
101	65	01100101
102	66	01100110
103	67	01100111
104	68	01101000
105	69	01101001
106	6A	01101010
107	6B	01101011
108	6C	01101100
109	6D	01101101
110	6E	01101110
111	6F	01101111
112	70	01110000
113	71	01110001
155	9B	10011011

DEC	HEX	BIN
115	73	01110011
116	74	01110100
117	75	01110101
118	76	01110110
119	77	01110111
120	78	01111000
121	79	01111001
122	7A	01111010
123	7B	01111011
124	7C	01111100
125	7D	01111101
126	7E	01111110
127	7F	01111111
128	80	10000000
129	81	10000001
130	82	10000010
131	83	10000011
132	84	10000100
133	85	10000101
134	86	10000110
135	87	10000111
136	88	10001000
137	89	10001001
138	8A	10001010
139	8B	10001011
140	8C	10001100
141	8D	10001101
142	8E	10001110
143	8F	10001111
144	90	10010000
145	91	10010001
146	92	10010010
147	93	10010011
148	94	10010100
149	95	10010101
150	96	10010110
151	97	10010111
152	98	10011000
153	99	10011001
154	9A	10011010
196	C4	11000100

DEC	HEX	BIN
156	9C	10011100
157	9D	10011101
158	9E	10011110
159	9F	10011111
160	A0	10100000
161	A1	10100001
162	A2	10100010
163	A3	10100011
164	A4	10100100
165	A5	10100101
166	A6	10100110
167	A7	10100111
168	A8	10101000
169	A9	10101001
170	AA	10101010
171	AB	10101011
172	AC	10101100
173	AD	10101101
174	AE	10101110
175	AF	10101111
176	B0	10110000
177	B1	10110001
178	B2	10110010
179	B3	10110011
180	B4	10110100
181	B5	10110101
182	B6	10110110
183	B7	10110111
184	B8	10111000
185	B9	10111001
186	BA	10111010
187	BB	10111011
188	BC	10111100
189	BD	10111101
190	BE	10111110
191	BF	10111111
192	C0	11000000
193	C1	11000001
194	C2	11000010
195	C3	11000011
237	ED	11101101

DEC	HEX	BIN
197	C5	11000101
198	C6	11000110
199	C7	11000111
200	C8	11001000
201	C9	11001001
202	CA	11001010
203	CB	11001011
204	CC	11001100
205	CD	11001101
206	CE	11001110
207	CF	11001111
208	D0	11010000
209	D1	11010001
210	D2	11010010
211	D3	11010011
212	D4	11010100
213	D5	11010101
214	D6	11010110
215	D7	11010111
216	D8	11011000
217	D9	11011001
218	DA	11011010
219	DB	11011011
220	DC	11011100
221	DD	11011101
222	DE	11011110
223	DF	11011111
224	E0	11100000
225	E1	11100001
226	E2	11100010
227	E3	11100011
228	E4	11100100
229	E5	11100101
230	E6	11100110
231	E7	11100111
232	E8	11101000
233	E9	11101001
234	EA	11101010
235	EB	11101011
236	EC	11101100
247	F7	11110111

DEC	HEX	BIN
238	EE	11101110
239	EF	11101111
240	F0	11110000
241	F1	11110001
242	F2	11110010
243	F3	11110011
244	F4	11110100
245	F5	11110101
246	F6	11110110

DEC	HEX	BIN
248	F8	11111000
249	F9	11111001
250	FA	11111010
251	FB	11111011
252	FC	11111100
253	FD	11111101
254	FE	11111110
255	FF	11111111