

**Date:** 03/19/18

**TSB Number:** TSB-0006

**Route to:** Modernization/Service Manager

**Reference:** Main and Emergency Brake Board Swap

**Subject:** Brake pick activation is falsely triggering, causing excessive roll back or extended brake drop delay time, resulting in entrapment.

**Action:** Required

**Equipment:** SRA Traction Controller, SRD DC Controller

**Fix:** Swap the existing brake board with an updated brake board.

**Hardware:** Smartrise will be sending an updated brake board.

**Do the following:**

1. Replace the existing brake board with the new one. This must be done on all installed jobs. (No wiring change needed)
2. Re-adjustments of the pick and hold voltage will be required after installation of the replacement boards.

**Affected job(s) on file:**